





Thank you for your recent PENN gear purchase. No matter where you fish or what you fish for, you can depend PENN to perform in any battle day in and day out. Now it's time to get your product registered and get out on the water.

<https://register.pennfishing.com>

| KEY NO. | PART NO. | PENN STYLE NO. | DESCRIPTION               |
|---------|----------|----------------|---------------------------|
| 1       | 1632368  | 1-BTLIV3000    | Housing                   |
| 1E      | 1489173  | 1E-SSVI3500    | Housing Slope             |
| 1J      | 1489177  | 1J-SSVI3500    | Housing Slope Screw       |
| 8       | 1529181  | 8-BTLIII3000   | Main Gear                 |
| 8A      | 1191028  | 8A-3000SG      | Shim                      |
| 15      | 1632337  | 15-BTLIV3000   | Handle Assembly           |
| 19      | 1529183  | 19-BTLIII3000  | Pinion Gear               |
| 19A     | 1191252  | 19A-3000SG     | Pinion Bushing            |
| 20      | 1308050  | 20-CFT3000     | Ball Bearing (2 req)      |
| 20A     | 1308051  | 20A-CFT3000    | Upper Pinion Ball Bearing |
| 20B     | 1211610  | 20D-5000BTL    | Housing Ball Bearing      |
| 21      | 1308052  | 21-CFT3000     | Bearing Retainer          |
| 21A     | 1192644  | 21A-3000SG     | Retainer Screw (3 req)    |
| 21B     | 1308053  | 21B-CFT3000    | Collar                    |
| 22      | 1203997  | 43B-3000PUR    | Bail Pivot Cover Screw    |
| 24      | 1529184  | 24-BTLIII3000  | Bail Wire Assembly        |
| 25      | 1529185  | 25-BTLIII3000  | Bail Holder               |
| 27      | 1632338  | 27-BTLIV3000   | Rotor                     |
| 27A     | 1632369  | 27A-BTLIV3000  | Bail Pivot Cover          |
| 28      | 1529188  | 28-BTLIII3000  | Trip Lever                |
| 31      | 1308063  | 31-CFT3000     | Bail Arm Screw (2 req)    |

| KEY NO. | PART NO. | PENN STYLE NO. | DESCRIPTION               |
|---------|----------|----------------|---------------------------|
| 32      | 1191586  | 32-3000SG      | Bail Spring               |
| 34      | 1609391  | 34-WRTHIII3000 | Bail Arm                  |
| 34C     | 1489198  | 34C-SSVI3500   | Pivot Arm                 |
| 35      | 1489199  | 35-SSVI3500    | Line Roller               |
| 35A     | 1489200  | 35A-SSVI3500   | Roller Bearing            |
| 36      | 1191699  | 36-3000SG      | Bail Stud Screw           |
| 38      | 1632370  | 38-BTLIV3000   | Rotor Nut                 |
| 38A     | 1308069  | 38A-CFT3000    | Rotor Locking Plate Screw |
| 38D     | 1308070  | 38D-CFT3000    | Rotor Nut Washer          |
| 38F     | 1632375  | 38F-BTLIV3000  | Main Shaft Seal Ring      |
| 39      | 1529379  | 39-BTLIII3000  | Main Shaft Assembly       |
| 43      | 1485219  | 43-PURIII3000  | Crosswind Block           |
| 43A     | 1191818  | 43A-3000SG     | Crosswind Block Plate     |
| 43B     | 1489213  | 43B-SSVI3500   | Plate Screw               |
| 44      | 1191843  | 44-3000SG      | Crosswind Block Screw     |
| 45      | 1632371  | 45-BTLIV3000   | Housing Cover             |
| 46      | 1192645  | 21A-5000SG     | Cover Screw (4 req)       |
| 47      | 1632372  | 47-BTLIV3000   | Spool Assembly            |
| 47D     | 1489217  | 47D-SSVI3500   | Line Clip                 |
| 47F     | 1489218  | 47F-SSVI3500   | Line Clip Spring          |
| 47H     | 1489219  | 47H-SSVI3500   | Line Clip Spring Screw    |

| KEY NO. | PART NO. | PENN STYLE NO.  | DESCRIPTION            |
|---------|----------|-----------------|------------------------|
| 48      | 1211604  | 48-3000SG       | Click Tongue           |
| 48A     | 1214226  | 48A-3000SG      | Click Tongue Washer    |
| 48B     | 1489220  | 48B-SSVI3500    | Spool Click Screw      |
| 49      | 1211605  | 49-3000SG       | Click Tongue Spring    |
| 51      | 1308078  | 51-CFT3000      | Drag Retaining Ring    |
| 52      | 1632373  | 52-BTLIV3000    | Drag Knob Assembly     |
| 56      | 1308080  | 56-CFT3000      | Drag Washer (3 req)    |
| 57      | 1192043  | 57-3000SG       | Keyed Washer (3 req)   |
| 60      | 1529383  | 60-BTLIII3000   | Thrust Washer          |
| 95B     | 1308081  | 95B-CFT3000     | Rotor Locking Plate    |
| 98C     | 1308082  | 98C-CFT3000     | Clutch/Sleeve Assembly |
| 98W     | 1204004  | 98W-3000PUR     | Clutch Washer (2 req)  |
| 132     | 1529384  | 132-BTLIII3000  | Roller Washer          |
| 132A    | 1489225  | 132A-SSVI3500   | Line Roller Bushing    |
| 226     | 1632374  | 226-BTLIV3000   | Rear Cover             |
| 226A    | 1529386  | 226A-BTLIII3000 | Rear Cover Screw       |
| 231     | 1485217  | 231-PURIII3000  | Crosswind Gear         |
| 231B    | 1489230  | 231B-SSVI3500   | Crosswind Gear Screw   |
| 233     | 1632346  | 233-BTLIV1000   | Bearing Cover Assy     |