




# PARTS LIST FOR MODEL CLASH3000/CLASH3000AU/CLASH4000/CLASH4000AU



| KEY NO. | PART NO. | DESCRIPTION                       |
|---------|----------|-----------------------------------|
| 1       | 1385500  | 1-CLA3000 Body Assembly           |
| 1       | 1385501  | 1-CLA4000 Body Assembly           |
| 8       | 1385502  | 8-CLA3000 Drive Gear              |
| 8A      | 1276920  | 8A-SSV3500 Drive Gear Shim Washer |
| 11      | 1385504  | 11-CLA3000 Rotor Seal             |
| 13      | 1385505  | 13-CLA3000 Spool Clicker Gear     |
| 15      | 1385506  | 15-CLA3000 Handle Assembly        |
| 15      | 1385507  | 15-CLA3000AU Handle Assembly      |
| 15E     | 1417805  | 15E-CLA3000 Handle Knob           |
| 15E     | 1417807  | 15E-CLA3000AU Handle Knob         |
| 15L     | 1417804  | 15L-CLA2000 Handle Knob Seal      |
| 19      | 1385508  | 19-CLA3000 Pinion Gear            |
| 19A     | 1277424  | 19A-SSV3500 Pinion Gear Washer    |

| KEY NO. | PART NO. | DESCRIPTION                                 |
|---------|----------|---|
| 19C     | 1385529  | 19C-CLA2000 Pinion Gear POM Bushing         |
| 20A     | 1385530  | 20A-CLA3000 Sealed Ball Bearing             |
| 20B     | 1385531  | 20B-CLA3000 Sealed Ball Bearing (2req.)     |
| 20C     | 1385532  | 20C-CLA3000 Sealed Ball Bearing             |
| 20D     | 1385533  | 20D-CLA3000 Main Shaft Sealed Ball Bearing  |
| 21      | 1385534  | 21-CLA3000 Pinion Bearing Retainer          |
| 21A     | 1276926  | 21A-SSV3500 Pinion Retainer Screw (3req.)   |
| 21B     | 1385535  | 21B-CLA3000 Pinion Ball Bearing Collar      |
| 21C     | 1385536  | 21C-CLA3000 Pinion Ball Bearing Collar Seal |
| 22      | 1122148  | 22-CLA3000 Rotor Cover Screw                |
| 24      | 1385537  | 24-CLA3000 Bail Assembly                    |
| 24      | 1385538  | 24-CLA4000 Bail Assembly                    |
| 24C     | 1417806  | 24C-CLA3000 Handle Knob Cap                 |
| 24C     | 1417808  | 24C-CLA3000AU Handle Knob Cap               |
| 25      | 1385539  | 25-CLA3000 Bail Holder                      |
| 25C     | 1385540  | 25C-CLA3000 Bail Arm Bushing (2req.)        |
| 27      | 1385541  | 27-CLA3000 Rotor Assembly                   |
| 27      | 1385542  | 27-CLA4000 Rotor Assembly                   |
| 27A     | 1389427  | 27A-CLA3000 Rotor Cover                     |
| 27A     | 1389434  | 27A-CLA4000 Rotor Cover                     |
| 28      | 1385543  | 28-CLA3000 Bail Trip Lever                  |
| 28      | 1385544  | 28-CLA4000 Bail Trip Lever                  |
| 28B     | 1385546  | 28B-CLA3000 Rotor Brake Spring              |
| 28C     | 1385547  | 28C-CLA3000 Rotor Brake Seal                |
| 28D     | 1385545  | 28D-CLA3000 Rotor Brake                     |
| 31      | 1385548  | 31-CLA3000 Bail Arm Screw (2req.)           |

| KEY NO. | PART NO. | DESCRIPTION                                     |
|---------|----------|---|
| 32      | 1385549  | 32-CLA3000 Bail Spring                          |
| 34      | 1385550  | 34-CLA3000 Bail Arm                             |
| 34C     | 1385551  | 34C-CLA3000 Pivot Arm                           |
| 35      | 1276939  | 35-SSV3500 Line Roller                          |
| 35A     | 1385552  | 35A-CLA3000 Line Roller Sealed Ball Bearing     |
| 35B     | 1418393  | 35B-CLA3000 Ball Bearing(2req.)                 |
| 35B     | 1377606  | 35B-CLA3000AU Ball Bearing(2req.)               |
| 36      | 1277061  | 36-SSV5500 Line Roller Screw                    |
| 36B     | 1417809  | 36B-CLA6000-Bail Arm Screw Washer               |
| 38      | 1385623  | 38-CLA2000 Rotor Nut                            |
| 38A     | 1385624  | 38A-CLA2000 Rotor Nut Lock Plate Screw          |
| 38D     | 1385555  | 38D-CLA3000 Rotor Washer                        |
| 39      | 1385556  | 39-CLA3000 Main Shaft                           |
| 39      | 1385557  | 39-CLA4000 Main Shaft                           |
| 39A     | 1385558  | 39A-CLA3000 Spool Adjust Washer                 |
| 39B     | 1385559  | 39B-CLA3000 Main Shaft Pin                      |
| 39C     | 1385560  | 39C-CLA3000 Main Shaft Seal                     |
| 40      | 1385588  | 40-CLA3000 Main Shaft Bushing O-Ring            |
| 43      | 1385561  | 43-CLA3000 O/S Slider                           |
| 43A     | 1385562  | 43A-CLA3000 O/S Slider Guide                    |
| 43B     | 1277070  | 43B-SSV5500 O/S Slider Guide Screw(2req.)       |
| 43F     | 1385563  | 43F-CLA3000 Guide Shaft                         |
| 44      | 1385564  | 44-CLA3000 Main Shaft Screw                     |
| 45      | 1385565  | 45-CLA3000 Body Cover                           |
| 45      | 1385566  | 45-CLA4000 Body Cover                           |
| 46      | 1385567  | 46-CLA3000 Body Cover Screw (3req.)             |
| 46T     | 1341500  | 3-SSV7500LC Screw                               |
| 47      | 1385569  | 47-CLA3000 Spool Assembly                       |
| 47      | 1385570  | 47-CLA4000 Spool Assembly                       |
| 47C     | 1385571  | 47C-CLA3000 Drag Cover                          |
| 47D     | 1276953  | 47D-SSV3500 Line Clip                           |
| 47F     | 1385572  | 47F-CLA3000 Line Clip Retainer                  |
| 47P     | 1385573  | 47P-CLA3000 Spool                               |
| 47P     | 1385574  | 47P-CLA4000 Spool                               |
| 47T     | 1341544  | 47T-SSV7500LC Rear Cover Screw(3req.)           |
| 48      | 1385578  | 48-CLA3000 Spool Click Plate                    |
| 48B     | 1385581  | 48B-CLA3000 Spool Clicker Spring Screw          |
| 48D     | 1385579  | 48D-CLA3000 Spool Clicker Spacer Ring           |
| 49      | 1385580  | 49-CLA3000 Spool Click Spring                   |
| 49A     | 1341547  | 49A-SSV7500LC Spool Clicker Spring Screw(2req.) |
| 52      | 1385582  | 52-CLA3000 Drag Knob Assembly                   |
| 53S     | 1385583  | 53S-CLA3000 Drag Knob Seal                      |
| 56      | 1385584  | 56-CLA3000 Drag Friction Washer (2req.)         |
| 57      | 1385585  | 57-CLA3000 Keyed Drag Washer (2req.)            |
| 57      | 1385586  | 57-CLA4000 Keyed Drag Washer (2req.)            |
| 63      | 1385587  | 63-CLA3000 Main Shaft Bushing                   |
| 95B     | 1385647  | 95B-CLA2000 Rotor Nut Locking Plate             |
| 98      | 1276966  | 98-SSV3500 Clutch/Sleeve Assembly               |
| 132     | 1277096  | 132-SSV5500 Line Roller Collar                  |
| 132A    | 1277097  | 132A-SSV5500 Line Roller Washer                 |
| 226     | 1385590  | 226-CLA3000 Rear Cover                          |
| 226A    | 1385591  | 226A-CLA3000 Rear Cover Screw                   |
| 231     | 1385592  | 231-CLA3000 O/S Gear                            |
| 231     | 1385593  | 231-CLA4000 O/S Gear                            |
| 231A    | 1385595  | 231A-CLA3000 O/S Gear Bushing                   |
| 231B    | 1385596  | 231B-CLA3000 O/S Gear Screw                     |
| 231C    | 1385594  | 231C-CLA3000 O/S Gear Washer                    |
| 231E    | 1385597  | 231E-CLA4000 Slow O/S Gear                      |
| 233A    | 1385598  | 233A-CLA3000 Handle Cap                         |