




## PARTS LIST FOR MODEL FRCIV6000



| KEY NO. | PART NO. | PENN STYLE NO. | DESCRIPTION               |
|---------|----------|----------------|---------------------------|
| 1       | 1577498  | 1-FRCIV6000    | Housing Assembly          |
| 4       | 1190937  | 4-5000SG       | Dog                       |
| 5       | 1190966  | 5-5000SG       | Dog Spring                |
| 6       | 1190979  | 6-5000SG       | Retaining Clip            |
| 8       | 1191019  | 8-5000SG       | Main Gear                 |
| 8A      | 1191030  | 8A-5000SG      | Shim                      |
| 10      | 1191066  | 10-5000SG      | A/R Holder                |
| 11      | 1191085  | 11-5000SG      | Bushing                   |
| 12      | 1313865  | 12-CFT8000     | A/R Bushing Spring        |
| 15      | 1577495  | 15-FRCIV5000   | Handle Assembly           |
| 19      | 1364030  | 19-BTLII5000   | Pinion Gear               |
| 19A     | 1191253  | 19A-5000SG     | Pinion Bushing            |
| 20      | 1204012  | 20-5000PUR     | Ball Bearing (3 req)      |
| 20A     | 1308090  | 20-CFT5000     | Upper Pinion Ball Bearing |
| 21      | 1192636  | 21-5000SG      | Bearing Retainer          |

| KEY NO. | PART NO. | PENN STYLE NO. | DESCRIPTION                        |
|---------|----------|----------------|------------------------------------|
| 21A     | 1192645  | 21A-5000SG     | Bearing Retainer Screw (3 req)     |
| 21B     | 1324209  | 21B-BTLII5000  | Collar                             |
| 22      | 1204018  | 22-6000PUR     | Bail Pivot Cover Screw             |
| 24      | 1365746  | 24-FRCII6000   | Bail Wire                          |
| 25      | 1308093  | 25-CFT5000     | Bail Holder                        |
| 27      | 1524124  | 27-FRCIII6000  | Rotor                              |
| 27A     | 1365748  | 27A-FRCII6000  | Bail Pivot Cover                   |
| 28      | 1365749  | 28-FRCII6000   | Trip Lever                         |
| 31      | 1365740  | 31-FRCII5000   | Bail Arm Screw (2 req)             |
| 32      | 1200520  | 32-6000SG      | Bail Spring                        |
| 34      | 1308103  | 34-CFT6000     | Bail Arm                           |
| 34C     | 1191652  | 34C-5000SG     | Pivot Arm                          |
| 35      | 1308066  | 35-CFT3000     | Line Roller                        |
| 35A     | 1308067  | 35A-CFT3000    | Line Roller Bushing                |
| 36      | 1191699  | 36-3000SG      | Bail Stud Screw                    |
| 38      | 1191729  | 38-5000SG      | Rotor Nut                          |
| 38A     | 1365741  | 38A-FRCII5000  | Screw                              |
| 38D     | 1308104  | 38D-CFT5000    | Rotor Nut Washer                   |
| 39      | 1488472  | 39-PURIII6000  | Main Shaft Assembly                |
| 43      | 1308107  | 43-CFT5000     | Crosswind Block                    |
| 43A     | 1191820  | 43A-5000SG     | Crosswind Block Plate              |
| 43B     | 1191736  | 38A-5000SG     | Crosswind Block Plate Screw(2 req) |
| 44      | 1191845  | 44-5000SG      | Crosswind Block Screw (2 req)      |
| 45      | 1514576  | 45-FRCIII6000  | Housing Cover Assy                 |
| 46      | 1191903  | 46-5000SG      | Housing Cover Screw (3 req)        |
| 46B     | 1191908  | 46B-5000SG     | Housing Cover Washer (3 req)       |
| 47      | 1577499  | 47-FRCIV6000   | Spool Assembly                     |
| 48      | 1211625  | 48-5000SG      | Click Tongue                       |
| 48A     | 1211626  | 48A-5000SG     | Click Tongue Washer                |
| 48B     | 1192658  | 22-2000SG      | Bail Pivot Cover Screw             |
| 49      | 1211627  | 49-5000SG      | Click Tongue Spring                |
| 51      | 1308112  | 51-CFT5000     | Drag Retaining Ring                |
| 52      | 1514319  | 52-FRCIII5000  | Drag Knob Assembly                 |
| 56      | 1308114  | 56-CFT5000     | Drag Washer (3 req)                |
| 57      | 1192044  | 57-5000SG      | Keyed Washer (3 req)               |
| 60      | 1211629  | 60-5000BTL     | Thrust Washer                      |
| 95B     | 1308115  | 95B-CFT5000    | Rotor Locking Plate                |
| 98C     | 1308116  | 98C-CFT5000    | Clutch/Sleeve Assembly             |
| 132     | 1192297  | 132-5000SG     | Roller Washer                      |
| 132A    | 1192302  | 132A-3000SG    | Line Roller Washer (2 req)         |
| 226     | 1308117  | 226-CFT5000    | Rear Cover                         |
| 226A    | 1192473  | 226A-3000SG    | Rear Cover Screw                   |
| 231     | 1200523  | 231-6000SG     | Crosswind Gear                     |
| 233     | 1514320  | 233-FRCIII5000 | Bearing Cover Assy                 |

407-FRCIV6000 Rev.0 23-11-2021

1558712