




PARTS LIST FOR MODEL PURSUIT 5000/6000
REEL PART NO.1190632/1190634



KEY NO.	PART NO.	DESCRIPTION
27A	1204023	27A-5000PUR Bail Pivot Cover
27A	1204025	27A-6000PUR Bail Pivot Cover
28	1204026	28-5000PUR Trip Lever
28	1204027	28-6000PUR Trip Lever
31	1203987	31-3000PUR Bail Arm Screw (2 req)
31	1204039	31-6000PUR Bail Arm Screw (2 req)
32	1203988	32-3000PUR Bail Spring
32	1200520	32-6000SG Bail Spring
34	1203989	34-3000PUR Bail Arm
34	1204042	34-6000PUR Bail Arm
34C	1203990	34C-3000PUR Pivot Arm
34C	1204044	34C-6000PUR Pivot Arm
35	1203991	35-3000PUR Line Roller
35A	1203992	35A-3000PUR Line Roller Bushing
36	1204047	36-5000PUR Bail Stud Screw
36	1203993	36-3000PUR Bail Stud Screw
38	1204049	38-5000PUR Rotor Nut
38A	1203995	38A-3000PUR Rotor Locking Plate Screw
39	1204051	39-5000PUR Spool Shaft Assembly
39	1214203	39-6000FRC Spool Shaft Assembly
43	1191805	43-5000SG Crosswind Block
43A	1191820	43A-5000SG Crosswind Block Plate
43B	1203997	43B-3000PUR Crosswind Block Plate Screw (2 req)
44	1191845	44-5000SG Crosswind Block Screw (2 req)
45	1204053	45-5000PUR Housing Cover
46	1204054	46-5000PUR Housing Cover Screw (4 req)
47	1204055	47-5000PUR Spool Complete
47	1204056	47-6000PUR Spool Complete
48	1211625	48-5000SG Click Tongue
48A	1211626	48A-5000SG Click Tongue Washer
48B	1211612	48B-5000SG Spool Click Screw
49	1211627	49-5000SG Click Tongue Spring
51	1287230	51-6000PUR Drag Retaining Ring
52	1204058	52-5000PUR Drag Knob Assembly
56	1192036	56-5000SG Drag Washer (5 req)
57	1192044	57-5000SG Keyed Washer (3 req)
58	1192053	58-5000SG Earred Washer (2 req)
60	1192062	60-5000SG Thrust Washer
95B	1192186	95B-5000SG Rotor Locking Plate
98C	1192215	98C-5000SG Clutch/Sleeve Assembly
132	1192297	132-5000SG Roller Washer
132A	1192302	132A-3000SG Line Roller Washer (2 req)
231	1192503	231-5000SG Crosswind Gear
231	1200523	231-6000SG Crosswind Gear
233	1204059	233-5000PUR Bearing Cover

KEY NO.	PART NO.	DESCRIPTION
1	1204007	1-5000PUR Housing
1	1204008	1-6000PUR Housing
8	1204009	8-5000PUR Main Gear
8A	1191030	8A-5000SG Shim
11	1191085	11-5000SG Bushing
15	1204010	15-5000PUR Handle Assembly
19	1204011	19-5000PUR Pinion
19A	1191253	19A-5000SG Pinion Bushing
20	1204012	20-5000PUR Lower Pinion Ball Bearing
20A	1204013	20A-5000PUR Upper Pinion Ball Bearing
20B	1204014	20B-5000PUR Housing Ball Bearing
20C	1204015	20C-5000PUR Housing Cover Ball Bearing
21	1192636	21-5000SG Bearing Retainer
21A	1204016	21A-5000PUR Bearing Retainer Screw (3 req)
21B	1192650	21B-5000SG Collar
22	1203978	22-3000PUR Bail Pivot Cover Screw
22	1204018	22-6000PUR Bail Pivot Cover Screw
24	1204019	24-5000PUR Bail Wire Assembly
24	1204020	24-6000PUR Bail Wire Assembly
27	1204021	27-5000PUR Rotor (w/weight & screw)
27	1204022	27-6000PUR Rotor (w/weight & screw)