




## PARTS LIST FOR MODEL AS SSVI6500



| KEY NO. | PART NO. | PENN STYLE NO. | DESCRIPTION                   |
|---------|----------|----------------|-------------------------------|
| 1       | 1489446  | 1-SSVI6500     | Housing Assembly              |
| 1F      | 1489419  | 1F-SSVI5500    | Main Gear Seal Ring(2 req)    |
| 1G      | 1489418  | 1G-SSVI5500    | Seal Plate(2 req)             |
| 1H      | 1489176  | 1H-SSVI3500    | Bearing Screw (6 req)         |
| 2L      | 1489447  | 2L-SSVI6500    | Housing Seal Ring             |
| 4       | 1489448  | 4-SSVI6500     | A/R Pawl                      |
| 5       | 1489422  | 5-SSVI5500     | Pawl Spring                   |
| 6       | 1190979  | 6-5000SG       | Retaining Clip                |
| 8       | 1489449  | 8-SSVI6500     | Main Gear                     |
| 8A      | 1485572  | 8B-PURIII5000  | Shim                          |
| 10      | 1489450  | 10-SSVI6500    | A/R Holder                    |
| 11      | 1489425  | 11-SSVI5500    | Bushing                       |
| 12      | 1489426  | 12-SSVI5500    | Bushing Spring                |
| 15      | 1489427  | 15-SSVI5500    | Handle Assembly               |
| 19      | 1489428  | 19-SSVI5500    | Pinion Gear                   |
| 19A     | 1489429  | 19A-SSVI5500   | Pinion Bushing                |
| 20      | 1308090  | 20-CFT5000     | Ball Bearing (4 req)          |
| 21      | 1489451  | 21-SSVI6500    | Bearing Retainer              |
| 21A     | 1192645  | 21A-5000SG     | Bearing Retainer Screw(3 req) |
| 21B     | 1489431  | 21B-SSVI5500   | Collar                        |
| 21C     | 1489303  | 21C-SSVI7500   | Bearing Retainer O-Ring       |
| 24      | 1489452  | 24-SSVI6500    | Bail Wire                     |

| KEY NO. | PART NO. | PENN STYLE NO. | DESCRIPTION                   |
|---------|----------|----------------|-------------------------------|
| 25      | 1489433  | 25-SSVI6500    | Bail Holder                   |
| 27      | 1489434  | 27-SSVI6500    | Rotor                         |
| 27A     | 1489435  | 27A-SSVI6500   | Bail Pivot Cover              |
| 28      | 1489436  | 28-SSVI6500    | Trip Lever                    |
| 28D     | 1489437  | 28D-SSVI6500   | Rotor Brake                   |
| 31      | 1489310  | 31-SSVI7500    | Bail Arm Screw (2 req)        |
| 32      | 1489397  | 32-SSVI5500    | Bail Spring                   |
| 34      | 1489438  | 34-SSVI6500    | Bail Arm                      |
| 34C     | 1489399  | 34C-SSVI5500   | Pivot Arm                     |
| 35      | 1489400  | 35-SSVI5500    | Line Roller                   |
| 35A     | 1242222  | 35A-5000BTL    | Line Roller Bearing           |
| 36      | 1191699  | 36-3000SG      | Bail Stud Screw               |
| 38      | 1489401  | 38-SSVI5500    | Rotor Nut                     |
| 38A     | 1489316  | 38A-SSVI7500   | Rotor Nut Cover Screw(3 req)  |
| 38E     | 1489203  | 38E-SSVI3500   | Rotor O-Ring(2 req)           |
| 38F     | 1489402  | 38F-SSVI5500   | Main Shaft Seal Ring          |
| 39      | 1489439  | 39-SSVI6500    | Main Shaft Assembly           |
| 39A     | 1489320  | 39A-SSVI7500   | Thrust Washer                 |
| 39B     | 1489321  | 39B-SSVI7500   | Spool Seal                    |
| 43      | 1489440  | 43-SSVI6500    | Crosswind Block               |
| 43A     | 1489405  | 43A-SSVI5500   | Crosswind Block Plate         |
| 43B     | 1489213  | 43B-SSVI3500   | Plate Screw (6 req)           |
| 44      | 1191845  | 44-5000SG      | Crosswind Block Screw (2 req) |
| 45      | 1489441  | 45-SSVI6500    | Housing Cover Assembly        |
| 46      | 1191903  | 46-5000SG      | Housing Cover Screw (3 req)   |
| 47      | 1489442  | 47-SSVI6500    | Spool Assembly                |
| 47D     | 1489408  | 47D-SSVI5500   | Line Clip                     |
| 47F     | 1489218  | 47F-SSVI3500   | Line Clip Spring              |
| 47H     | 1489219  | 47H-SSVI3500   | Line Clip Spring Screw        |
| 48      | 1211625  | 48-5000SG      | Click Tongue                  |
| 48A     | 1211626  | 48A-5000SG     | Click Tongue Washer           |
| 48B     | 1489327  | 48B-SSVI7500   | Spool Click Screw             |
| 49      | 1211627  | 49-5000SG      | Click Tongue Spring           |
| 51      | 1308112  | 51-CFT5000     | Drag Retaining Ring           |
| 52      | 1489409  | 52-SSVI5500    | Drag Knob Assembly            |
| 56      | 1308114  | 56-CFT5000     | Drag Washer (3 req)           |
| 57      | 1192044  | 57-5000SG      | Keyed Washer (3 req)          |
| 95B     | 1489223  | 95B-SSVI3500   | Rotor Locking Plate           |
| 98C     | 1308116  | 98C-CFT5000    | Clutch/Sleeve Assembly        |
| 132     | 1489410  | 132-SSVI5500   | Roller Washer                 |
| 132A    | 1489411  | 132A-SSVI5500  | Line Roller Bushing           |
| 226     | 1489443  | 226-SSVI6500   | Rear Cover                    |
| 226A    | 1489227  | 226A-SSVI3500  | Rear Cover Screw              |
| 231     | 1489444  | 231-SSVI6500   | Crosswind Gear                |
| 231A    | 1489445  | 231A-SSVI6500  | Crosswind Gear Washer         |
| 231B    | 1489338  | 231B-SSVI7500  | Crosswind Gear Screw          |
| 231C    | 1489339  | 231C-SSVI7500  | Crosswind Gear Sleeve         |
| 233     | 1489415  | 233-SSVI5500   | Bearing Cover Assembly        |

407-SSVI6500 Rev. 1 30-3-18

1481264