




PARTS LIST FOR MODELS SG7000/SG8000
REEL PART NO.1152123/1152124



KEY NO.	PART NO.	DESCRIPTION
27A	1191454	27A-7000SG Bail Pivot Cover
28	1191491	28-7000SG Trip Lever
28	1191494	28-8000SG Trip Lever
31	1191569	31-5000SG Bail Arm Screw
31A	1191575	31A-5000SG Bail Cam Screw
32	1200520	32-6000SG Bail Spring
34	1191634	34-7000SG Bail Arm
34C	1191656	34C-7000SG Pivot Arm
35	1191674	35-3000SG Line Roller
35A	1191683	35A-3000SG Line Roller Bearing
36	1191704	36-7000SG Bail Stud Screw
38	1191731	38-7000SG Rotor Nut
38A	1191736	38A-5000SG Rotor Locking Plate Screw
39	1191756	39-7000SG Spool Shaft
39	1191760	39-8000SG Spool Shaft
43	1191809	43-7000SG Crosswind Block
43A	1191821	43A-7000SG Crosswind Block Plate
43B	1191827	43B-5000SG Crosswind Block Plate Screw (2 req)
44	1191845	44-5000SG Crosswind Block Screw (2 req)
45	1191876	45-7000SG Housing Cover
45	1191882	45-8000SG Housing Cover
46	1191903	46-5000SG Housing Cover Screw (3 req)
46A	1191906	46A-3000SG Housing Cover Screw A
46B	1191908	46B-5000SG Housing Cover Washer (3 req)
47	1191945	47-7000SG Spool Complete
47	1191949	47-8000SG Spool Complete
48	1211625	48-5000SG Click Tongue
48A	1211626	48A-5000SG Click Tongue Washer
48B	1211612	48B-5000SG Spool Click Screw
49	1211627	49-5000SG Click Tongue Spring
51	1191980	51-7000SG Retaining Spacer
51A	1191986	51A-3000SG Retaining Screw (3 req)
52	1192000	52-7000SG Drag Knob
56	1192038	56-7000SG Drag Washer (5 req)
57	1192046	57-7000SG Keyed Washer (3 req)
58	1192055	58-7000SG Earred Washer (2 req)
60	1192062	60-5000SG Thrust Washer
95B	1192186	95B-5000SG Rotor Locking Plate
98C	1192215	98C-5000SG Clutch/Sleeve Assembly
132	1192298	132-7000SG Roller Washer
132A	1192302	132A-3000SG Line Roller Washer (2 req)
226	1192463	226-7000SG Rear Cover
226A	1192474	226A-7000SG Rear Cover Screw
231	1192507	231-7000SG Crosswind Gear
231A	1192511	231A-7000SG Bushing Crosswind Gear
231B	1192514	231B-7000SG Screw Crosswind Gear
233	1192523	233-5000SG Cover Assembly Bearing

KEY NO.	PART NO.	DESCRIPTION
1	1190842	1-7000SG Housing
1	1190848	1-8000SG Housing
4	1190939	4-7000SG A/R Dog
5	1190966	5-5000SG A/R Dog Spring
6	1190979	6-5000SG Retaining Clip
8	1191021	8-7000SG Main Gear
8A	1191031	8A-7000SG Shim
10	1191068	10-7000SG A/R Holder
11	1191087	11-7000SG Bushing
12	1191090	12-5000SG A/R Bushing Spring
15	1211633	15-7000BTL Handle Assembly
19	1191244	19-7000SG Pinion
20	1192613	20-5000SG Ball Bearing (2 req)
20B	1192621	20B-7000SG Ball Bearing (2 req)
21	1192636	21-5000SG Bearing Retainer
21A	1192645	21A-5000SG Bearing Retainer Screw (3 req)
21B	1192650	21B-5000SG Collar
22	1192662	22-7000SG Bail Pivot Cover Screw
24	1191316	24-7000SG Bail Wire Assembly
24	1191319	24-8000SG Bail Wire Assembly
27	1191424	27-7000SG Rotor (w/weight & screw)
27	1191428	27-8000SG Rotor (w/weight & screw)