



<u>KEY NO.</u>	<u>PENN STYLE NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	001 710	1180543	Housing w/Bushing
4	004 710	1180784	Dog
5	005 710	1180879	Dog Spring
6A	006A710	1180955	Eccentric
6B	006B700Z	1180965	Eccentric Liner
6D	006D710	1180977	Eccentric Spring
6E	006E710	1180985	Eccentric Lever
8	008 710	1181099	Main Gear w/Ratchet
13	013 710	1181354	Crosswind Screw
14	014 710	1181409	Crosswind Roller
15	015 710	1181495	Handle Assembly (Complete)
17	017 710	1181601	Handle Washer
19	019 710	1181709	Pinion Gear
20	020 704	1181790	Pinion Bearing
21	021 710	1181876	Bearing Retainer
22	022 109	1181912	Eccentric Screw
24	024 710	1182060	Bail Wire Assembly
27	027 710	1182275	Rotor Cup
27A	027AN710	1182335	Counterweight
27B	027B710	1182339	Screw
28	028 710	1182407	Bail Release Arm
29	029 710	1182463	Bail Release Screw
30	030 710	1182638	Bail Release Spring
31	031 019	1182654	Bearing Cover Screw (3 req.)
31A	031 710	1182676	Bail Screw
32	032 710	1182736	Bail Spring
34	034 710	1182828	Bail Arm
35	035 720	1182940	Line Roller
36	036 700	1183014	Bail Lock Nut
37	037 710	1183085	Rotor Cup Washer
38	038 710	1183157	Rotor Cup Nut
39	039 710	1183231	Spool Shaft Assembly
43	043 710	1183401	Crosswind Block
44	044 710	1183459	Crosswind Screw
45	045 710	1183524	Housing Cover
46	046 710	1183573	Housing Cover Screw
47	047 710	1183660	Spool Assembly(Complete)
47B	047B710	1183685	Click Screw
48	048 710	1183711	Click Tongue
48A	048A710	1183721	Click Bushing
49	049 710	1183741	Click Spring
51	051 710	1183796	Retaining Spring
52	052 710	1183833	Drag Knob
56	056 710	1183907	Drag Washer-HT100 (3 req.)
57	057 710	1183938	Metal Keyed Washer (2 req.)
58	058 710	1183961	Metal Washer (Octagon)
60	060 710	1184004	Thrust Washer (Teflon)
62A	062A716	1184034	Dog Screw