




**PARTS LIST FOR WAR20N and WAR30**  
REEL ASM. Nos. 1366200(WAR20N)&1366201(WAR30)



KEY NO.	PART NO.	PENN STYLE NO.	DESCRIPTION	KEY NO.	PART NO.	PENN STYLE NO.	DESCRIPTION
1	1383108	1-WAR20N	Right Side Plate Assembly(20N)	27	1383111	27-WAR20N	Left Side Plate(20N)
1	1383109	1-WAR30	Right Side Plate Assembly(30)	27	1383112	27-WAR30	Left Side Plate(30)
2	1383110	2-WAR20N	Right Side Ring	27C	1384185	27C-WAR20N	Screw
3	1384179	3-WAR15LW	Bridge	28	1383114	28-WAR20N	Left Side Ring
4	1382976	4-WAR15LW	Drag Washer	29	1383115	29-WAR20N	Spool (20N)
5	1382977	5-WAR15LW	Main Gear	29	1383116	29-WAR30	Spool (30)
6	1382978	6-WAR15LW	Tabbed Drag Washer(2 req)	29L	1383117	29L-WAR20N	Spool Assembly(20N)
7	1382999	7-WAR15LW	Keyed Metal Drag Washer	29L	1383118	29L-WAR30	Spool Assembly(30)
7H	1383000	7H-WAR15LW	Heavy Metal Drag Washer	33	1182754	33-113	Rod Clamp
8	1383001	8-WAR15LW	Spring Washer (4 req)	34	1182788	34-045	Screw (2 req)
9	1384180	9-WAR15LW	Spacing Sleeve	35	1383037	35-WAR15LW	Click Tongue
10	1383002	10-WAR15LW	Star Drag	36	1383038	36-WAR15LW	Click Button
10A	1383003	10A-WAR15LW	Star Click Retainer	38	1383039	38-WAR15LW	Screw (8 req)
10B	1383004	10B-WAR15LW	Star Click Washer	39A	1383041	39A-WAR15LW	Screw (2 req)
10C	1383005	10C-WAR15LW	Star Click Spring	40	1383042	40-WAR15LW	Ball Bearing
11	1383104	11-WAR30LW	Eccentric Jack	40B	1383044	40B-WAR15LW	Felt Washer
12	1383007	12-WAR15LW	Pinion Yoke	40C	1383045	40C-WAR15LW	Washer, Acetal Thrust
13	1383008	13-WAR15LW	Pinion	40D	1383046	40D-WAR15LW	Washer, Rubber Thrust
13R	1384184	13R-WAR20N	Retainer Ring	40E	1383047	40E-WAR15LW	Thrust Washer (2req)
15	1383009	15-WAR15LW	Anti Reverse Dog(2 req)	41	1383048	41-WAR15LW	Bushing
16	1383010	16-WAR15LW	Screw (2 req)	62	1383061	62-WAR15LW	Spring
18	1383011	18-WAR15LW	Pinion Yoke Spring (2 req)	66	1383290	66-WAR30LW	Click Ratchet
19	1383012	19-WAR15LW	Eccentric	69A	1383066	69A-WAR15LW	Retainer Ring (2 req)
20	1383013	20-WAR15LW	Eccentric Spring	98	1383119	98-WAR20N	Main Gear Shaft
21	1383106	21-WAR30LW	Eccentric Lever	98A	1383068	98A-WAR15LW	Clutch Housing
22	1383015	22-WAR15LW	Eccentric Screw	98B	1384182	98B-WAR15LW	Clutch
23	1383016	23-WAR15LW	Handle Assembly Screw	98R	1383069	98R-WAR15LW	Anti Reverse Ratchet
23A	1383017	23A-WAR15LW	Handle Lock Screw	98S	1383070	98S-WAR15LW	Clutch Sleeve
23B	1383018	23B-WAR15LW	Handle Screw Washer	120	1383071	120-WAR15LW	O-Ring
24	1383019	24-WAR15LW	Handle Assembly	149	1184702	149-045	Rod Clamp Nut (2 req)
24A	1383020	24A-WAR15LW	Handle Thrust Washer	149A	1184706	149-200	Hex Nut (2 req)
26	1383021	26-WAR15LW	Spool Tension Control Cap	154	1383077	154-WAR15LW	Click Button Washer
26A	1383022	26A-WAR15LW	Bushing	158	1383078	158-WAR15LW	Dog Pin(2req)
26B	1383023	26B-WAR15LW	Clutch Retainer	183	1383120	183-WAR20N	Frame Assembly(20N)
26C	1383024	26C-WAR15LW	Screw(2req)	183	1383121	183-WAR30	Frame Assembly(30)