



Please specify reel model number and number in reel foot when ordering parts.

TRI73LPB / TRI73LPX 26 00
1383409 / 1383408 34-13267-0

ITEM#	PART#	DESCRIPTION	ITEM#	PART#	DESCRIPTION
1	1415447	PALM SIDE COVER	41	1415424	CLUTCH CAM SPRING
2	1415448	CONTROL DIAL	42	1415425	CLUTCH CAM
3	1134431	CLICK SPRING	43	1134460	TAP SCREW
4	1134432	O-RING	44	1306777	YOKE
5	1415404	SLIDER CAM - B	45	1306778	YOKE SPRING
6	1306753	SLIDER CAM - A	46	1415426	PINION
7	1415405	COIL SPRING	47	1415428	BALL BEARING
8	1415406	SPOOL COVER	48	1134468	RETAINER
9	1415407	MAGNET PLATE	49	1415429	BEARING PLATE
10	1415408	MAGNET HOLDER	50	1134436	TAP SCREW
11	1415409	MAGNET	51	1415430	WASHER
12	1415410	MAGNET HOLDER SCREW	52	1415431	MAIN SHAFT
13	1415411	TAP SCREW	53	1065960	O/S GEAR
14	1415445	WASHER	54	1134471	RATCHET
15	1415412	BALL BEARING	55	1306789	WASHER
16	1134442	RING	56	1415432	DRIVE GEAR
17	1415449	PALM SIDE COVER ASSY	57	1415433	DRAG WASHER
18	1415450	SPOOL ASSEMBLY	58	1415434	D WASHER
19	1415451	RETAINER	59	1415435	WASHER
20	1415452	BUSHING	60	1134475	IAR BEARING
21	1415453	WORM SHAFT	61	1306791	SLEEVE
22	1415416	LEVEL WIND ASSY	62	1306792	BALL BEARING
23	1415417	PAWL	63	1415436	WASHER
24	1306763	WASHER	64	1134478	WASHER
25	1134448	LINE GUIDE NUT	65	1065971	SPRING WASHER
26	1415454	LEVEL WIND TUBE	66	1415458	STAR DRAG
27	1415455	BALL BEARING	67	1415438	WASHER
28	1415456	WASHER	68	1415459	HANDLE ASSEMBLY
29	1134451	GEAR	69	1415460	HANDLE NUT
30	1104799	RETAINER	70	1415441	HANDLE NUT RETAINER
31	1415418	THUMB BAR	71	1415461	HANDLE NUT SCREW
32	1415419	THUMB BAR SCREW	72	1415427	COIL SPRING
33	1415420	FRAME	73	1415443	THUMB SCREW
34	1306785	TAP SCREW	74	1415462	GEAR SIDE COVER
35	1415421	TAP SCREW	75	1306785	TAP SCREW
36	1134453	TAP SCREW	76	1104812	O-RING
37	1415457	FRONT COVER	77	1065949	BUSHING
38	1306769	LINE GUIDE SHAFT	78	1415445	WASHER
39	1306775	KICK LEVER SPRING	79	1415463	COLLAR
40	1415423	KICK LEVER	80	1153298	WASHER
			81	1415464	TENSION KNOB