



Please specify reel model number and number in reel foot when ordering parts.

PRES73LPB / PRES73LPX 26 00
1383407 / 1383406 34-13268-0

ITEM#	PART#	DESCRIPTION	ITEM#	PART#	DESCRIPTION
1	1415465	PALM SIDE COVER	42	1415424	CLUTCH CAM SPRING
2	1415403	CONTROL DIAL	43	1415425	CLUTCH CAM
3	1134431	CLICK SPRING	44	1134460	TAP SCREW
4	1134432	O-RING	45	1306777	YOKE
5	1415404	SLIDER CAM - B	46	1306778	YOKE SPRING
6	1306753	SLIDER CAM - A	47	1415426	PINION
7	1415405	COIL SPRING	48	1415428	BALL BEARING
8	1415406	SPOOL COVER	49	1134468	RETAINER
9	1415407	MAGNET PLATE	50	1134436	TAP SCREW
10	1415408	MAGNET HOLDER	51	1415429	BEARING PLATE
11	1415409	MAGNET	52	1415430	WASHER
12	1415410	MAGNET HOLDER SCREW	53	1415431	MAIN SHAFT
13	1415411	TAP SCREW	54	1065960	O/S GEAR
14	1415445	WASHER	55	1134471	RATCHET
15	1415412	BALL BEARING	56	1306789	WASHER
16	1134442	RING	57	1415470	DRIVE GEAR
17	1415466	PALM SIDE COVER ASSY	58	1415433	DRAG WASHER
18	1415467	SPOOL ASSEMBLY	59	1415434	D WASHER
19	1415451	RETAINER	60	1415435	WASHER
20	1415452	BUSHING	61	1134475	IAR BEARING
21	1415468	BALL BEARING	62	1306791	SLEEVE
22	1415453	WORM SHAFT	63	1306792	BALL BEARING
23	1415416	LEVEL WIND ASSY	64	1415436	WASHER
24	1415469	PAWL	65	1415471	SPRING PLATE
25	1306763	WASHER	66	1415472	CLICK SPRING
26	1134448	LINE GUIDE NUT	67	1065971	SPRING WASHER
27	1415454	LEVEL WIND TUBE	68	1415473	STAR DRAG
28	1415455	BALL BEARING	69	1415438	WASHER
29	1415456	WASHER	70	1415459	HANDLE ASSEMBLY
30	1134451	GEAR	71	1415460	HANDLE NUT
31	1104799	RETAINER	72	1415441	HANDLE NUT RETAINER
32	1406086	THUMB BAR	73	1415442	HANDLE NUT SCREW
33	1415419	THUMB BAR SCREW	74	1415427	COIL SPRING
34	1415420	FRAME	75	1415443	THUMB SCREW
35	1306785	TAP SCREW	76	1415474	GEAR SIDE COVER
36	1415421	TAP SCREW	77	1306785	TAP SCREW
37	1134453	TAP SCREW	78	1104812	O-RING
38	1415422	FRONT COVER	79	1065949	BUSHING
39	1306769	LINE GUIDE SHAFT	80	1415445	WASHER
40	1306775	KICK LEVER SPRING	81	1415463	COLLAR
41	1415423	KICK LEVER	82	1153298	WASHER
			83	1415475	TENSION KNOB