

MODEL:PFL1806USPIN

Rev:01

ITEM	DESCRIPTION	SAP#
1	FRAME ASSY	1210913
2	DRAG CLICK SPRING	1210747
3	DRAG CLICK PIN	1210750
4	DRAG STEM	1210803
5	DRAG KNOB	1210844
6	"E" WASHER	1208999
7	DRAG GEAR BASE	1210798
8	GEAR NUT	1210788
9	DRAG SPRING WASHER	1210687
10	SPOOL WASHER	1210686
11	FRICITION WASHER	1210677
12	SPOOL ASSY	1210963
13	SPOOL WASHER	1210681
14	RETAINING WASHER	1210669
15	CLICK LEVER ASSY	1210992
16	CLICK LEVER SCREW	1210680
17	MAIN SHAFT	1210778
18	BEARING 10×6×2.5	1207116
19	PINION	1210787
20	MAIN SHAFT SPRING	1210744

ITEM	DESCRIPTION	SAP#
21	"E" WASHER	1208999
22	N-R PAWL	1210825
23	DRIVE GEAR	1210805
24	BEARING 11×7×2.5	1207354
25	WASHER	1200798
26	ANTI-REVERSE LEVER	1210847
27	ANTI-REVERSE SPRING	1210754
28	WASHER	1200813
29	BUSHING RETANER	1210845
30	SCREW	1210682
31	BODY FRAME ASSY	1210915
32	N-R LEVER	1210846
33	N-R LEVER SCREW	1210693
34	P. U. H ASSY	1210962
35	FRONT CONE ASSY	1210914
36	HANDLE ASSY	1210916
37	WASHER	1210665
38	CRANK MTG SCREW	1210683
39	SIDE CAP	1210834

EXPLODED VIEW

