

ARBOR 7430

Rev: 01

ITEM	DESCRIPTION	SAP#	ITEM	DESCRIPTION	SAP#
1	DRAG KNOB ASSY	1200744	34	SCREW	1200799
2	SPOOL LIP SCREW	1200826	35	CLUTCH RETAINER	1200861
3	SPOOL RING	1200746	36	BEARING $\Phi 14 \times \Phi 8 \times 4$	1200801
4	KEY WASHER	1200747	37	BEARING SLEEVE	1200802
5	DRAG WASHER	1200748	38	ONE WAY CLUTCH	1200864
6	SPOOL SUB-ASSY	1200769	39	PINION	1200804
6A	Complete Spool Solid	1200770	40	CLUTCH SPRING	1200868
6A	COMPLETE SPOOL VENTE	1214411	41	SPRING	1200806
7	CLICK GEAR WASHER	1200771	42	N-R LEVER SHAFT	1200807
8	MAIN SHAFT WASHER	1200772	43	SCREW	1200872
9	BEARING $\Phi 10 \times \Phi 6 \times 3$	1200834	44	N-R LEVER	1200871
10	SLEEVE	1200774	45	DUST CAP	1200873
11	CLICK GEAR	1200775	46	BEARING $\Phi 11 \times \Phi 7 \times 3$	1200811
12	MAIN SHAFT	1200776	47	DRIVE GEAR	1200812
13	SCREW	1200777	48	GEAR WASHER	1200813
14	BAIL HOLDER	1200778	49	BEARING $\Phi 13 \times \Phi 7 \times 4$	1200814
15	BAIL ASSY	1200779	50	BODY COVER ASSY	1200815
16	LINE ROLLER WASHER	1200841	51	SCREW	1200901
17	BEARING $\Phi 7 \times \Phi 4 \times 2.5$	1200843	52	SCREW	1200817
18	LINE ROLLER	1200842	53	CRANK ARM ASSY	1200818
19	LINE ROLLER COLLAR	1200844	54	SCREW	1200904
20	SCREW	1200784	55	O/S SLIDER	1200820
21	BAIL ARM	1200785	56	O/S GEAR	1200821
22	SCREW	1200786	57	BEARING $\Phi 8 \times \Phi 5 \times 2.5$	1200822
23	SCREW	1200848	58	REAR COVER	1200823
24	BAIL ARM COVER	1200788	59	BODY ASSY	1200824
25	BAIL ARM SPRING	1200789	60	SCREW	1214413
26	BAIL ARM GUIDE	1200790	61	CLICKER	1214414
27	TRIP PLUNGER	1200791	62	SPRING	1214415
28	ROTOR SUB-ASSY	1200792	63	BUSHING	1214416
29	SCREW	1200794	64	SCREW	1214417
30	NUT WASHER	1200856	65	SCREW	1210689
31	ROTOR NUT	1200796	66	HOUSING	1214418
32	FRAME BUSHING	1200797	67	FOOT	1214429
33	CLUTCH WASHER	1200877			

EXPLODED VIEW

