



No.	PART NAME	No.	PART NAME	No.	PART NAME	No.	PART NAME
1	Lever Plate	23	Line Guide Assembly	45	Drag Washer "D"	68	Drag Spring Washer
2	Lever Plate Spring	24	Line Guide Pawl	46	Sleeve	69	Click Plate(B)
3	Lock Lever	25	Spacer(Optional)	47	Clutch Bar	70	Star Drag
4	Lock Lever Screw(B)	26	Pawl Cap	48	Clutch Bar Screw	71	Leaf Spring
5	Left Side Cover	27	Frame	49	Clutch Bar Plate	72	Handle Assembly
6	Lock Pin	28	Worm Shaft	50	Clutch Bar Support	73	Handle Nut
7	Lock Pin Spring	29	Worm Shaft Pin	51	Clutch Link	74	Handle Nut Cap
8	Spool Cover	30	Worm Shaft Bushing"A"	52	Yoke Holder	75	Handle Nut Cap Screw
9	Spool Cover Screw	31	Idler(S) Washer(Optional)	53	Clutch Spring	76	"O"Ring
10	Spool Spacer(A)	32	Idler(S)	54	Clutch Spring Bushing	77	Right Side Cover Bushing
11	Ball Bearing	33	Ball Bearing	55	Clutch Cam	78	Spool Spacer(B)
12	Bearing Retainer	34	Crank Shaft Spacer	57	Cam Plate Screw	79	Tansion Washer
13	E-Ring	35	E-Ring	58	Pinion Yoke	80	Cast Control Cap
14	Worm Shaft Washer(Optional)	36	Bearing Plate	59	Pinion Yoke Spring	81	Sleeve Washer
15	Worm Shaft Bushing "B"	37	Bearing Plate Screw	60	Pinion Gear	82	Hood Assembly
16	Pillar	38	Idler(L) Washer	61	Return Pawl Spring	83	Cam Plate Screw(B)
17	Line Guide Pipe	39	Idler(L)	62	Return Pawl	84	Click Spring
18	Brake Collar(White)	40	Crank Shaft	63	Cam Plate	85	"O"Ring
19	Spool Assembly(1B/B)	41	Ratchet	64	Right Side Cover	86	Bearing Retainer
20	Right Side Cover Screw(A)	42	Ratchet Washer	65	Right Side Cover Screw(B)		
21	Front Cover Screw	43	Drive Gear	66	Right Side Cover Screw(C)		
22	Front Cover	44	Drag Washer "B"	67	One Way Bearing		