



No.	PARS NAME	No.	PART NAME	No.	PART NAME
001	Spool Ass'y	23	Pawl Cap	48	One Way Bearing
2	Left Side Cover	24	Stabilizer Bar	49	Sleeve
3	Frame Ass'y	25	Carriage Screw Ass'y	50	Spring Washer
4	Left Side Cover Screw	28	Set Plate Ass'y	53	Star Drag Ass'y
5	Washer	29	Return Pawl	55	Handle Ass'y
6	Ball Bearing	30	Return Pawl Spring	56	Handle Screw
7	Retainer	32	Clutch Arm	59	"O" Ring
8	Push Lever Screw	34	Clutch Arm Spring	60	Washer
9	Push Lever Spring	35	Pinion	61	Right Cover Screw
10	Push Lever Plate	36	Yoke	62	Screw
11	Push Lever Pin	37	Yoke Spring	63	Tansion Spring
12	Push Lever Cover Pin	39	Gear Shaft	64	Tansion Washer
13	Push Lever	40	Ball Bearing	65	Control Cap
14	Push Lever Cover	41	Idle Gear	67	Ball Bearing
15	Retainer	42	Ratchet	81	Yoke Bush
16	Retainer	43	Drive System Washer	82	Idle Gear**
18	Carriage Screw Bush	44	Drive Gear	84	Ball Bearing
19	Level Wind Guide	45	Smooth Washer		
21	Line Guide Holder	46	"D" Washer		
22	Line Guide Pawl	47	Right Side Cover Ass'y		