



No.	PART NAME	No.	PART NAME	No.	PART NAME	No.	PART NAME
1	Handle Cover	23	Drag Washer	45	Clutch Lever Shaft	67	Retaining Ring
2	Main Retaining Screw	24	Main Gear	46	Supporting Bushing	68	Spool Assembly
3	Handle Retaining Plate Screw	25	Drag Washer	47	Clutch Lever	69	Stopper Ring
4	Handle Retaining Plate	26	Ratchet Gear	48	Screw	70	Magnet Holder Assembly
5	Handle Assembly	27	Return Clutch Spring	49	Return Clutch	71	Stopper Ring
6	Handle Spring Washer	28	Ratchet Gear Shaft	50	Traverse Can Gear	72	Ball Bearing
7	Star Handle Assembly	29	Connecting Gear	51	Washer	73	Brake Piece
8	Star Handle Claw	30	Ball Bearing	52	Supporting Bushing	74	ON/OFF Holder Assembly
9	Star Handle Claw Screw	31	Bushing	53	Front Cover	75	O Ring
10	Click Gear	32	Pinion Gear	54	Stabilizer Bar	76	Screw
11	Collar	33	Clutch Spring	55	Line Guide Block Cap	77	Adjusting Gear
12	Drag Spring Washer	34	Clutch Bar	56	Claw	78	Left Side Plate
13	Handle Side Plate Screw	35	Clutch Cam Screw	57	Line Guide Block Assembly	79	Brake Adjusting Dial
14	Handle Side Plate Cover	36	Clutch Cam	58	Line Guide Block Bar	80	Coil Spring
15	Cast Control Knob	37	Connecting Plate	59	Main Body Assembly	81	Click
16	Rubber	38	Dead Point Spring	60	Spacer	82	O Ring
17	Brake Piece	39	Ball Bearing	61	Stopper	83	Screw
18	Brake Adjusting Spring	40	Bushing	62	Screw	84	ON/OFF Spring
19	Ball Bearing	41	Retaining Ring	63	Traverse Cam Pin	85	ON/OFF Screw
20	Handle Side Plate Assembly	42	Washer	64	Traverse Cam	86	Left Side Plate Cover
21	One Way Clutch Collar	43	Kick Claw Spring	65	Bushing		
22	Drag Washer	44	Kick Claw	66	Washer		