



| No. | PART NAME | No. | PART NAME | No. | PART NAME | No. | PART NAME |
|-------|------------------------------|-------|----------------------|-------|---------------------------|-------|------------------------|
| 1 | Handle Cover | 23 | Main Gear | 41 | Kick Claw | 61 | Bushing |
| 2 | Handle Retaining Screw | 23(L) | Main Gear | 41(L) | Kick Claw | 62 | Washer |
| 3 | Handle Retaining Plate Screw | 24 | Drag Washer | 42 | Clutch Lever Shaft | 63 | Retaining Ring |
| 4 | Handle Retaining Plate | 25 | Ratchet Gear | 43 | Supporting Bushing | 64 | Spool Assembly |
| 5 | Handle Assembly | 26 | Return Clutch Spring | 44 | Clutch Lever | 64(L) | Spool Assembly |
| 5(L) | Handle Assembly | 27 | Ratchet Gear Shaft | 45 | Screw | 65 | Stopper Ring |
| 6 | Handle Spring Washer | 27(L) | Ratchet Gear Shaft | 46 | Return Clutch | 66 | Magnet Holder Assembly |
| 7 | Star Handle Assembly | 28 | Connecting Gear | 46(L) | Return Clutch | 67 | Stopper Ring |
| 7(L) | Star Handle Assembly | 29 | Ball Bearing | 47 | Traverse Can Gear | 68 | Ball Bearing |
| 8 | Star Handle Claw | 30 | Pinion Gear | 48 | Washer | 69 | Brake Piece |
| 9 | Star Handle Claw Screw | 30(L) | Pinion Gear | 49 | Supporting Bushing | 70 | ON/OFF Holder Assembly |
| 10 | Click Gear | 31 | Clutch Spring | 49(L) | Supporting Bushing | 71 | O Ring |
| 11 | Collar | 32 | Clutch Bar | 50 | Front Cover | 72 | Screw |
| 12 | Drag Spring Washer | 32(L) | Clutch Bar | 50(L) | Front Cover | 73 | Adjusting Gear |
| 13 | Handle Side Plate Screw | 33 | Clutch Cam Screw | 51 | Stabilizer Bar | 74 | Left Side Plate |
| 14 | Cast Control Knob | 34 | Clutch Cam | 52 | Line Guide Block Cap | 74(L) | Left Side Plate |
| 15 | Rubber | 34(L) | Clutch Cam | 53 | Claw | 75 | Brake Adjusting Dial |
| 16 | Brake Piece | 35 | Connecting Plate | 54 | Line Guide Block Assembly | 76 | Coil Spring |
| 17 | Brake Adjusting Spring | 35(L) | Connecting Plate | 55 | Line Guide Block Bar | 77 | Click |
| 18 | Ball Bearing | 36 | Dead Point Spring | 56 | Main Body Assembly | 78 | O Ring |
| 19 | Handle Side Plate Assembly | 36(L) | Dead Point Spring | 56(L) | Main Body Assembly | 79 | Screw |
| 19(L) | Handle Side Plate Assembly | 37 | Ball Bearing | 57 | Stopper | 80 | ON/OFF Spring |
| 20 | One Way Clutch Collar | 38 | Retaining Ring | 58 | Screw | 81 | ON/OFF Screw |
| 21 | Drag Washer | 39 | Washer | 59 | Traverse Cam Pin | 82 | Left Side Plate Cover |
| 22 | Drag Washer | 40 | Kick Claw Spring | 60 | Traverse Cam | 82(L) | Left Side Plate Cover |