



No.	PART NAME	No.	PART NAME	No.	PART NAME	No.	PART NAME	No.	PART NAME
1	Spool Ass'y	23	Pawl Cap	42	Ratchet	61	Right Cover Screw	78	Idle Gear Collar
2	Left Side Cover	24	Stabilizer Bar	43	Drive System Washer	62	Osculate Screw	79	Push Lever Cam
3	Frame Ass'y	25	Carriage Screw Ass'y	44	Drive Gear	63	Tension Spring	87	Digital Case Ass'y
4	Left Side Cover Screw	28	Set Plate Ass'y	47	Right Side Cover Ass'y	64	Tension Washer	88	Sensor Gear
5	Washer	29	Return Pawl	48	One Way Ball Bearing	65	Control Cap	89	Sensor Gear Collar
6	Bushing	30	Return Pawl Spring	49	Sleeve	66	Clutch Arm Bush	91	Battery
7	Retainer	31	Washer	50	Spring Washer	67	Washer	92	Packing Tube
8	Lever Screw	32	Clutch Arm	51	Retainer	68	Sound Lever	93	Digital Case Cover
9	Lever Spring	33	Clutch Arm Spring Bush	52	Click Disk Washer	69	Leaf Spring	94	Screw
13	Push Lever	34	Clutch Arm Spring	53	Star Drag Ass'y	70	Ball Bearing	95	Rulon Washer
16	Retainer	35	Pinion	54	Friction Washer	71	Spool Gear	96	"D" Washer
17	Carriage Screw Washer	36	Yoke	55	Handle Ass'y	72	Sound Gear	97	"A" Washer
18	Carriage Screw Bush	37	Yoke Spring	56	Handle Nut	73	Sound Claw Ass'y	98	"D" Washer
19	Level Wind Guide	38	Washer	57	Handle Nut Cap	74	Screw		
20	Retainer	39	Gear Shaft	58	Handle Nut Cap Screw	75	Screw		
21	Line Guide Holder	40	Ball Bearing	59	"O" Ring	76	Washer		
22	Line Guide Pawl	40-1	Bearing Collar	60	Washer	77	Idle Gear		