



No.	PART NAME	No.	PART NAME	No.	PART NAME	No.	PART NAME
1	Handle Cover	23	Main Gear	41	Kick Claw	61	Bushing
2	Handle Retaining Screw	23(L)	Main Gear	41(L)	Kick Claw	62	Washer
3	Handle Retaining Plate Screw	24	Drag Washer	42	Clutch Lever Shaft	63	Retaining Ring
4	Handle Retaining Plate	25	Ratchet Gear	43	Supporting Bushing	64	Spool Assembly
5	Handle Assembly(2B/B)	26	Return Clutch Spring	44	Clutch Lever	64(L)	Spool Assembly
5(L)	Handle Assembly(2B/B)	27	Ratchet Gear Shaft	45	Screw	65	Stopper Ring
6	Handle Spring Washer	27(L)	Ratchet Gear Shaft	46	Return Clutch	66	Magnet Holder Assembly
7	Star Handle Assembly	28	Connecting Gear	46(L)	Return Clutch	67	Stopper Ring
7(L)	Star Handle Assembly	29	Ball Bearing	47	Traverse Can Gear	68	Ball Bearing
8	Star Handle Claw	30	Pinion Gear	48	Washer	69	Brake Piece
9	Star Handle Claw Screw	30(L)	Pinion Gear	49	Supporting Bushing	70	ON/OFF Holder Assembly
10	Click Gear	31	Clutch Spring	49(L)	Supporting Bushing	71	O Ring
11	Collar	32	Clutch Bar	50	Front Cover	72	Screw
12	Drag Spring Washer	32(L)	Clutch Bar	50(L)	Front Cover	73	Adjusting Gear
13	Handle Side Plate Screw	33	Clutch Cam Screw	51	Stabilizer Bar	74	Left Side Plate
14	Cast Control Knob	34	Clutch Cam	52	Line Guide Block Cap	74(L)	Left Side Plate
15	Rubber	34(L)	Clutch Cam	53	Claw	75	Brake Adjusting Dial
16	Brake Piece	35	Connecting Plate	54	Line Guide Block Assembly	76	Coil Spring
17	Brake Adjusting Spring	35(L)	Connecting Plate	55	Line Guide Block Bar	77	Click
18	Ball Bearing	36	Dead Point Spring	56	Main Body Assembly	78	O Ring
19	Handle Side Plate Assembly	36(L)	Dead Point Spring	56(L)	Main Body Assembly	79	Screw
19(L)	Handle Side Plate Assembly	37	Ball Bearing	57	Stopper	80	ON/OFF Spring
20	One Way Clutch Collar	38	Retaining Ring	58	Screw	81	ON/OFF Screw
21	Drag Washer	39	Washer	59	Traverse Cam Pin	82	Left Side Plate Cover
22	Drag Washer	40	Kick Claw Spring	60	Traverse Cam	82(L)	Left Side Plate Cover