



No.	PART NAME	No.	PART NAME	No.	PART NAME	No.	PART NAME
1	Screw	20	Left Line Guide Shaft Gear	39	Swerving Gear	58	Key Washer
2	Screw	21	Line Guide Shaft Bushing	40	Gear	59	Washer
3	Left Side Plate Guard	22	Level Wind Guard	41	Clutch	60	Washer
4	Click Flip Knob	23	Worm Shaft for Level Wind	42	Clutch Spring	61	Drag Washer
5	Left Side Plate	24	Line Guide Shaft Bushing	43	Pawl Pin	62	Spring Washer
6	Washer	25	Right Line Guide Shaft Gear	44	Pawl	63	Bushing
7	Ball Bearing	26	E-Clip	45	Pawl Spring	64	Bushing
8	Transmission Gear	27	Line Guide Shaft Seat	46	E-Clip	65	Washer
9	Spool Ass'y	28	Line Guide Pawl	47	Washer	66	Star Drag Ass'y
10	Ball Bearing	29	Line Guide Shaft Nut	48	Bushing	67	Handle Spring Plate
11	Main Body	30	Clutch Flip Plate	49	Clutch Flip Plate	68	Handle Screw
12	Click Slice	31	Pinion Gear	50	Spring	69	Handle Screw Cap
13	E-Clip	32	Clutch Plate	51	Gear	70	Drag Nut Spring
14	Middle Gear	33	Clutch Press Spring	52	Gear Shaft	71	Washer
15	E-Clip	34	Right Side Plate	53	Gear	72	Drag Nut
16	Spring Clip	35	Line Counter	54	Washer	73	Flip Lever
17	Screw	36	Screw	55	C-clip	74	Screw
18	Screw	37	Light Side Plate Guard	56	Main Gear	75	Handle Ass'y
19	Pin	38	E-Clip	57	Drag Washer		(Including 2 Ball Bearings)