



| No. | PARTS NAMES | No. | PARTS NAMES | No. | PARTS NAMES |
|-----|-----------------------|-----|------------------------|-----|------------------------|
| 001 | Spool Ass'y | 23 | Pawl Cap | 47 | Right Side Cover Ass'y |
| 2 | Left Side Cover | 24 | Stabilizer Bar | 48 | One Way Bearing |
| 3 | Frame Ass'y | 25 | Carriage Screw Ass'y | 49 | Sleeve |
| 4 | Left Side Cover Screw | 28 | Set Plate Ass'y | 50 | Spring Washer |
| 5 | Washer | 29 | Return Pawl | 51 | Retainer |
| 6 | Ball Bearing | 30 | Return Pawl Spring | 52 | Click Disk Washer |
| 7 | Retainer | 31 | Washer | 53 | Star Drag Ass'y |
| 8 | Push Lever Screw | 32 | Clutch Arm | 54 | Friction Washer |
| 9 | Push Lever Spring | 33 | Clutch Arm Spring Bush | 55 | Pivoting Handle |
| 10 | Push Lever Plate | 34 | Clutch Arm Spring | 56 | Handle Nut |
| 11 | Push Lever Pin | 35 | Pinion | 57 | Handle Nut Cap |
| 12 | Push Lever Cover Pin | 36 | Yoke | 58 | Handle Nut Cap Screw |
| 13 | Push Lever | 37 | Yoke Spring | 59 | "O" Ring |
| 14 | Push Lever Cover | 38 | Washer | 60 | Washer |
| 15 | Retainer | 39 | Gear Shaft | 61 | Right Cover Screw |
| 16 | Retainer | 40 | Ball Bearing | 62 | Oscillating Screw |
| 17 | Carriage Screw Washer | 41 | Idle Gear | 63 | Tansion Spring |
| 18 | Carriage Screw Bush | 42 | Ratchet | 64 | Tansion Washer |
| 19 | Level Wind Guide | 43 | Drive System Washer | 65 | Control Cap |
| 20 | Retainer | 44 | Drive Gear | 66 | Clutch Arm Bush |
| 21 | Line Guide Holder | 45 | Smooth Washer | | |
| 22 | Line Guide Pawl | 46 | "D"Washer | | |