


25,30,35,40



No.	PART NAME	No.	PART NAME	No.	PART NAME	No.	PART NAME
1	Drag Assembly	15	Arm Lever Cover	29	Bearing Fix Screw	43	Drive Gear ADJ Washer
2	Stop Ring	16	Arm Lever Cover Screw	30	Change Lever	44	Ball Bearing
3	D Washer	17	Kick Lever	31	Sleeve	45	Body Cover Assembly
4	B Washer	18	Kick Lever Spring	32	Clutch Bearing Assembly	46	Handle Screw Cap
5	A Washer	19	Kick Lever Cover	33	Clutch Bearing Washer		Handle Screw
6	Spool Assembly	20	Kick Lever Cover Screw	34	Ball Bearing		Handle Screw Washer
7	Main Shaft	21	Line Slider Screw	35	Pinion	47	Body Cover Screw
8	Click Gear	22	Arm Lever	36	Anti Reverse Cam	48	O/S Gear
9	Rotor Nut	23	Arm Lever Screw	37	Body	49	O/S Slider
10	Rotor Washer	24	Line Roller	38	Anti Reverse Cam Spring	50	O/S Slider S/C
11	Rotor	25	Bail Assembly	39	Anti Reverse Lever	51	Handle Assembly
12	Bail Spring Guide	26	Bail Holder S/C	40	Anti Reverse Lever Screw	52	Spool ADJ Washer
13	Bail Spring	27	Bearing Cover Screw	41	Bush	53	Retainer
14	Bail Spring Holder	28	Ball Bearing	42	Drive Gear		