



- | | | |
|----------------------------------|------------------------------------|--|
| 1. Spool washer | 23. Mainshaft screw | |
| 2. Spool click ratchet | 24. Clutch bearing cover screw (3) | |
| 3. Rotor nut-bearing | 25. Clutch bearing cover | |
| 4. Rotor nut retainer screw | 26. Front bearing shim | |
| 5. Rotor nut retainer | 27. Front bearing | |
| 6. Main shaft | 28. Bearing seat | |
| 7. Rotor cover top screw | 29. Clutch bearing spring | |
| 8. Rotor body | 30. Clutch bearing | |
| 9. Line roller screw | 31. Rotor bearing | |
| 10. Roller screw shield | 32. Pinion gear | |
| 11. Roller shield | 33. Handle boss cover | |
| 12. Roller shim (2) | 34. Main body | |
| 13. Roller bearing | 35. Body plate screw | |
| 14. Line roller | 36. Body plate | |
| 15. Bail wire assembly | 37. Oscillation gear bushing | |
| 16. Bail hinge | 38. Oscillation gear | |
| 17. Rotor cover bushing (2) | 39. Oscillation block | |
| 18. Rotor cover (A) | 40. Rear shaft support | |
| 19. Rotor cover bottom screw (2) | 41. Bail trip wire | |
| 20. Bail spring pin bushing | 42. Bail pivot | |
| 21. Bail spring pin | 43. Rotor cover (B) | |
| 22. Bail spring | 44. Drag knob assembly | |
| | 45. Protective shield | |
| | 46. Drag retainer spring | |
| | 47. Top keyed washer | |
| | 48. Friction washer (3) | |
| | 49. Eared washer (2) | |
| | 50. Keyed washer | |
| | 51. Spool assembly | |
| | 52. Spool shell | |
| | 53. A/R switch cam | |
| | 54. Switch cam spring | |
| | 55. A/R switch | |
| | 56. AR switch screw | |
| | 57. Main gear | |
| | 58. Main gear shim | |
| | 59. Main gear bearing (2) | |
| | 60. Sideplate | |
| | 61. Sideplate screw (4) | |
| | 62. Handle assembly | |

