


# QUANTUM®

## Blu BL20PTs



# ReelSchematic

**Quantum BL20PTs Spinning Reel Part List**

| Key # | Description                  | Qty | Part No.  | Key # | Description                  | Qty | Part No.  |
|-------|------------------------------|-----|-----------|-------|------------------------------|-----|-----------|
| 1     | Drag Knob Assembly           | 1   | BAA332-06 | 31    | Clutch Bearing Adapter       | 1   | BAA190-01 |
| 2     | Retainer Ring                | 1   | BAA038-01 | 32    | Clutch Unit                  | 1   | BAA363-01 |
| 4     | Drag Washer "B"              | 3   | BAA033-01 | 33    | Pinion Ball Bearing          | 1   | BAA028-01 |
| 5     | Drag Washer "D"              | 2   | BAA080-01 | 34    | Pinion Bushing               | 2   | BAA213-01 |
| 6     | Drag Washer "A"              | 1   | BAA081-01 | 35    | Pinion                       | 1   | BAA011-01 |
| 7     | Spool Assembly               | 1   | BAA320-51 | 36    | Stopper Cam                  | 1   | BAA090-02 |
| 8     | Rotor Nut Lock Screw         | 1   | BAA094-01 | 37    | Clutch Spring                | 1   | BAA216-01 |
| 9     | Spool Adjust Washer          | 2   | BAA030-01 | 38    | Stopper Cam Spring           | 1   | BAA089-01 |
| 10    | Click Gear                   | 1   | BAA037-01 | 39    | Stopper Lever                | 1   | BAA059-03 |
| 11    | Rotor Nut                    | 1   | BAA006-01 | 40    | Stopper Lever Screw          | 1   | BAA135-01 |
| 12    | Main Shaft                   | 1   | BAA015-01 | 41    | Handle Screw Assembly        | 1   | BAA354-03 |
| 13    | Arm Lever Screw              | 2   | BAA042-01 | 42    | Rear Cap Screw (Front)       | 1   | CAA168-01 |
| 14    | Rotor                        | 1   | BAA009-07 | 43    | Body Assembly                | 1   | BAA301-07 |
| 15    | Kick Lever                   | 1   | BAA019-01 | 44    | Body Rear Cap                | 1   | BAA140-02 |
| 16    | Actuator                     | 1   | BAA031-01 | 45    | Tapping Screw                | 1   | CAA094-01 |
| 17    | Actuator Spring              | 1   | BAA022-01 | 46    | Main Shaft Screw             | 1   | BAA100-01 |
| 18    | Arm Lever Cover              | 1   | BAA087-01 | 47    | O/S Slider                   | 1   | BAA025-02 |
| 19    | Arm Lever Cover Screw        | 2   | BAA077-01 | 48    | O/S Gear                     | 1   | BAA053-02 |
| 20    | Line Roller Screw            | 1   | BAA108-01 | 49    | O/S Gear Ball Bearing        | 1   | BAA158-01 |
| 21    | Arm Lever                    | 1   | BAA007-07 | 50    | O/S Slider Retainer          | 1   | BAA078-01 |
| 22    | Line Roller Collar           | 1   | CAA102-01 | 51    | Body Ball Bearing            | 1   | BAA157-01 |
| 23    | Line Roller Washer           | 1   | BAA102-01 | 52    | Drive Gear                   | 1   | BAA012-02 |
| 24    | Line Roller                  | 1   | BAA004-04 | 53    | Drive Gear Adjust Wahser     | 1   | BAA105-01 |
| 25    | Line Roller Ball Bearing     | 1   | GH202-01  | 54    | Side Cover Ball Bearing      | 1   | CAA157-01 |
| 26    | Bail Assembly                | 1   | BAA347-03 | 55    | Side Cover Assembly          | 1   | BAA323-06 |
| 27    | Rotor Adjust Washer          | 2   | BAA110-01 | 56    | Side Cover Screw             | 3   | BAA085-01 |
| 28    | Tapping Screw (Flat head)    | 3   | CAA057-01 | 57    | Side Cover Screw (Flat head) | 1   | BAA057-01 |
| 29    | Clutch Stack Retainer        | 1   | CAA040-01 | 58    | Handle Assembly              | 1   | BAA418-06 |
| 30    | Clutch Retainer Ball Bearing | 1   | UK028-01  |       |                              |     |           |