




Catalyst - CT30PTi & CT40PTi

Kinetic - KT30PTi & KT40PTi



| KEY No. | DESCRIPTION | CT30PTi | CT40PTi | KT30PTi | KT40PTi |
|---------|------------------------|----------|----------|----------|----------|
| 1 | DRAG KNOB ASSEMBLY | SQ332-01 | TQ332-01 | SQ332-03 | TQ332-03 |
| 2 | DRAG RETAINER | RQ038-01 | RQ038-01 | RQ038-01 | RQ038-01 |
| 3 | DRAG WASHER "D" | SQ080-01 | SQ080-01 | SQ080-01 | SQ080-01 |
| 4 | DRAG WASHER "B" | RQ033-01 | RQ033-01 | RQ033-01 | RQ033-01 |
| 5 | DRAG WASHER "D" | RQ080-01 | RQ080-01 | RQ080-01 | RQ080-01 |
| 6 | DRAG WASHER "A" | RQ081-01 | RQ081-01 | RQ081-01 | RQ081-01 |
| 7 | SPOOL SLEEVE | SQ160-01 | TQ160-01 | SQ160-01 | TQ160-01 |
| 8 | SPOOL ASSEMBLY | SQ321-52 | TQ321-52 | SQ321-51 | TQ321-51 |
| 9 | SPOOL WASHER | RQ030-01 | RQ030-01 | RQ030-01 | RQ030-01 |
| 10 | CLICK GEAR | RQ037-01 | RQ037-01 | RQ037-01 | RQ037-01 |
| 11 | MAIN SHAFT BUSHING | SQ214-01 | SQ214-01 | SQ214-01 | SQ214-01 |
| 12 | ROTOR NUT | TH006-01 | TH006-01 | TH006-01 | TH006-01 |
| 13 | ROTOR NUT LOCK SCREW | RQ094-01 | RQ094-01 | RQ094-01 | RQ094-01 |
| 14 | E-CLIP | GH034-01 | GH034-01 | GH034-01 | GH034-01 |
| 15 | MAIN SHAFT | SQ015-01 | TQ015-01 | SQ015-01 | TQ015-01 |
| 16 | E-CLIP | GH034-01 | GH034-01 | GH034-01 | GH034-01 |
| 17 | BAIL ASSEMBLY | SQ347-51 | TQ347-51 | SQ347-51 | TQ347-51 |
| 18 | LINE ROLLER BEARING | GH202-01 | GH202-01 | GH202-01 | GH202-01 |
| 19 | LINE ROLLER | CH004-01 | CH004-01 | CH004-01 | CH004-01 |
| 20 | LINE ROLLER WASHER | DH102-01 | DH102-01 | DH102-01 | DH102-01 |
| 21 | LINE ROLLER COLLAR | CH102-01 | CH102-01 | CH102-01 | CH102-01 |
| 22 | ARM LEVER ASSEMBLY | SQ307-01 | SQ307-01 | SQ307-03 | SQ307-03 |
| 23 | LINE SLIDER SCREW | AQ108-07 | AQ108-07 | AQ108-07 | AQ108-07 |
| 24 | KICK LEVER | SQ019-01 | TQ019-01 | SQ019-01 | TQ019-01 |
| 25 | ARM LEVER COVER | SQ087-01 | TQ087-01 | SQ087-01 | TQ087-01 |
| 26 | ARM LEVER COVER WASHER | SQ142-01 | SQ142-01 | SQ142-01 | SQ142-01 |
| 27 | ARM LEVER COVER SCREW | GU077-15 | GU077-15 | GU077-15 | GU077-15 |
| 28 | ROTOR ASSEMBLY | SQ309-52 | TQ309-52 | SQ309-51 | TQ309-51 |
| 29 | CLUTCH ASSEMBLY | SQ360-01 | SQ360-01 | SQ360-01 | SQ360-01 |
| 30 | CLUTCH WASHER | RQ167-01 | RQ167-01 | RQ167-01 | RQ167-01 |

| KEY No. | DESCRIPTION | CT30PTi | CT40PTi | KT30PTi | KT40PTi |
|---------|--------------------------|----------|----------|----------|----------|
| 31 | CLUTCH SLEEVE | SQ139-01 | SQ139-01 | SQ139-01 | SQ139-01 |
| 32 | PINION BALL BEARING | UK028-01 | UK028-01 | UK028-01 | UK028-01 |
| 33 | PINION GEAR | SQ011-01 | SQ011-01 | SQ011-01 | SQ011-01 |
| 34 | PINION BUSHING | SQ141-01 | SQ141-01 | SQ141-01 | SQ141-01 |
| 35 | BEARING SCREW | RQ041-01 | RQ041-01 | RQ041-01 | RQ041-01 |
| 36 | ANTI REVERSE PAWL SPRING | RQ061-01 | RQ061-01 | RQ061-01 | RQ061-01 |
| 37 | ANTI-REVERSE PAWL | SQ063-01 | SQ063-01 | SQ063-01 | SQ063-01 |
| 38 | ANTI-REVERSE PAWL SCREW | RQ077-01 | RQ077-01 | RQ077-01 | RQ077-01 |
| 39 | ANTI REVERSE CAM | RQ090-01 | RQ090-01 | RQ090-01 | RQ090-01 |
| 40 | ANTI REVERSE CAM SPRING | RQ089-01 | RQ089-01 | RQ089-01 | RQ089-01 |
| 41 | ANTI REVERSE LEVER | RQ059-01 | RQ059-01 | RQ059-01 | RQ059-01 |
| 42 | HANDLE CAP SCREW | RQ073-01 | RQ073-01 | RQ073-01 | RQ073-01 |
| 43 | HANDLE SCREW WASHER | TH105-01 | TH105-01 | TH105-01 | TH105-01 |
| 44 | BODY ASSEMBLY | SQ301-52 | SQ301-54 | SQ301-51 | SQ301-53 |
| 45 | BODY REAR COVER | SQ140-51 | SQ140-51 | SQ140-51 | SQ140-51 |
| 46 | BODY REAR COVER WASHER | RQ142-01 | RQ142-01 | RQ142-01 | RQ142-01 |
| 47 | BODY REAR COVER SCREW | RQ062-01 | RQ062-01 | RQ062-01 | RQ062-01 |
| 48 | O/S GEAR BALL BEARING | EH158-01 | EH158-01 | EH158-01 | EH158-01 |
| 49 | OSCILLATOR GEAR | SQ053-51 | TQ053-51 | SQ053-51 | TQ053-51 |
| 50 | OSCILLATOR SLIDER | SQ025-01 | SQ025-01 | SQ025-01 | SQ025-01 |
| 51 | MAIN SHAFT SCREW | RQ100-01 | RQ100-01 | RQ100-01 | RQ100-01 |
| 52 | GEAR SHAFT BALL BEARING | BL157-01 | BL157-01 | BL157-01 | BL157-01 |
| 53 | DRIVE GEAR | SQ012-01 | SQ012-01 | SQ012-01 | SQ012-01 |
| 54 | ADJUST WASHER | GU105-13 | GU105-13 | GU105-13 | GU105-13 |
| 55 | GEAR SHAFT BALL BEARING | BL157-01 | BL157-01 | BL157-01 | BL157-01 |
| 56 | BODY COVER | SQ023-52 | SQ023-54 | SQ023-51 | SQ023-53 |
| 57 | BODY COVER SCREW WASHER | RQ142-01 | RQ142-01 | RQ142-01 | RQ142-01 |
| 58 | BODY COVER SCREW | SQ057-01 | SQ057-01 | SQ057-01 | SQ057-01 |
| 59 | BODY COVER SCREW | RQ057-01 | RQ057-01 | RQ057-01 | RQ057-01 |
| 60 | HANDLE ASSEMBLY | SQ318-52 | SQ318-52 | SQ318-51 | SQ318-51 |