


# QUANTUM<sup>®</sup>

## CSP120PTSE





## CSP120PTSE

### Quantum CSP120PTSE Spinning Reel Part List

Key #	Description	Part No.	Qty.	Key #	Description	Part No.	Qty.
1	Drag Knob Assembly	RAB332-01	1	27	Screw	JX107-03	3
2	Spool Kit Includes	UAB421-01	1	28	Ball Bearing Holder Assembly	RAB3190-01	1
	2A - Retaining Ring	RAB038-01	1	29	O-Ring	VBP164-01	1
	2B - Drag Washer "D"	RAB080-01	4	30	Pinion Bushing "Top"	TAB214-01	1
	2C - Drag Washer "B"	RAB033-01	7	31	Pinion Ball Bearing	DP058-02	1
	2D - Drag Washer "A"	RAB081-01	4				
	2E - Spool Bushing	RAB022-01	1	32-A	One Way Clutch	VBP063-01	1
	2F - Spool	UAB021-01	1	32-B	Clutch Sleeve	TAB139-01	1
	2G - Spool Ball Bearing	CP058-03	1	33	Spacer	TAB141-01	1
	2H - Key Washer	UAB033-01	1	34	Ratchet	TAB060-01	2
	2J - Magnum Drag Plate	TAB039-01	1				
	2K - Spool Click Spring Holder	SAB114-01	1	35-A	Pinion	TAB011-01	1
	2M - Spool Click Spring	RAB069-01	1	35-B	Drive Gear Assembly	TAB312-01	1
	2N - Click Claw	RAB103-01	1	36	Pinion Bushing "Bottom"	VBQ058-01	1
	2P- Click Claw Pin	VBP114-01	1	37	Screw	CF107-02	2
	2Q - Magnum Drag Retainer	TAB225-01	1	38	Breaking Pad "A"	TAB145-01	1
	2R - Screw	HX107-04	3	39	Handle Screw Cap	RAB054-02	1
3	Spool Adjust Washer	RAA065-01	1	40	Body Assembly	TAB301-01	1
4	Main Shaft Assembly	TAB315-01	1	41	Washer	TAB048-01	1
5	Screw	JX125-01	2	42	Drain Cap	TAB238-01	1
6	RotorNut Retainer	TAB118-01	1	43	AR Pawl Pad	TAB122-01	1
7	Rotor Nut	TAB006-01	1	44	Anti Reverse Pawl	TAB063-01	1
8	Washer	RAB110-01	1	45	AR Pawl Screw	TAB111-01	1
9	Rotor Assembly	TAB309-01	1	46	Seal	TAB262-01	2
10	Rotor Bushing	RAB106-02	1	47	Ball Bearing	CF017-02	2
11	E-Clip	KQ034-01	1	48	Drive Gear Adjust Washer	DF035-01	1
12	Rotor Bushing	RAB106-01	1	49	Side Cover	TAB023-01	1
13	Kick Lever Unit	TAB419-01	1	50	Seal - Side Cover	TAB254-01	1
14	Rotor Cover	TAB087-01	1	51	Breaking Pad "B"	TAB140-01	1
15	Rotor Cover Screw	QW053-04	2	52	Screw	CF107-02	2
16	Pin	RAB042-02	1	53	Side Cover Cosmetic Washer	TAB075-01	1
17	Bushing	SAB106-01	2	54	Side Cover Cosmetic Ring	TAB142-02	1
18	Bail Assembly	TAB347-01	1	55	Side Cover Screw	VBP057-03	4
19	Ball Bearing	CT157-02	2	56	O/S Gear Bushing	UAB158-01	1
20	Line Roller	RAB004-01	1	57	O/S Gear Assembly	TAB353-01	1
21	Line Roller Washer	RAB102-01	2	58	O/S Gear Ball Bearing	CH027-01	1
22	Arm Lever Assembly	TAB307-01	1	59	O/S Gear Screw	VAB111-01	1
23	Pin	RAB042-01	1	60	O/S Slider Assembly	TAB325-01	1
24	Washer	VBP167-01	1	61	Main Shaft Screw	RQ100-01	2
25	Screw	BAA108-02	1	62	Handle Assembly	TAB318-01	1
26	Washer	XAB110-01	1				