



| KEY # | DESCRIPTION            | CI30PTs  | KEY # | DESCRIPTION              | CI30PTs  |
|-------|------------------------|----------|-------|--------------------------|----------|
| 1     | DRAG KNOB ASSEMBLY     | RT332-02 | 32    | PINION BALL BEARING      | UK028-01 |
| 2     | DRAG RETAINER          | RQ038-01 | 33    | PINION GEAR              | SQ011-01 |
| 3     | DRAG WASHER "D"        | SQ080-01 | 34    | PINION BUSHING           | SQ141-01 |
| 4     | DRAG WASHER "B"        | RQ033-01 | 35    | BEARING SCREW            | RQ041-01 |
| 5     | DRAG WASHER "D"        | RQ080-01 | 36    | ANTI REVERSE PAWL SPRING | RQ061-01 |
| 6     | DRAG WASHER "A"        | RQ081-01 | 37    | ANTI-REVERSE PAWL        | SQ063-01 |
| 7     | SPOOL SLEEVE           | SQ160-01 | 38    | ANTI-REVERSE PAWL SCREW  | RQ077-01 |
| 8     | SPOOL ASSEMBLY         | SQ321-53 | 39    | ANTI REVERSE CAM         | RQ090-01 |
| 9     | SPOOL WASHER           | RQ030-01 | 40    | ANTI REVERSE CAM SPRING  | RQ089-01 |
| 10    | CLICK GEAR             | RQ037-01 | 41    | ANTI REVERSE LEVER       | RQ059-01 |
| 11    | MAIN SHAFT BUSHING     | SQ214-01 | 42    | HANDLE CAP SCREW ASSY    | AT373-01 |
| 12    | ROTOR NUT              | TH006-01 | 43    | HANDLE SCREW WASHER      | AT029-01 |
| 13    | ROTOR NUT LOCK SCREW   | RQ094-01 | 44    | BODY ASSEMBLY            | SQ301-55 |
| 14    | E-CLIP                 | GH034-01 | 45    | BODY REAR COVER          | SQ140-51 |
| 15    | MAIN SHAFT             | SQ015-01 | 46    | BODY REAR COVER WASHER   | RQ142-01 |
| 16    | E-CLIP                 | GH034-01 | 47    | BODY REAR COVER SCREW    | RQ062-01 |
| 17    | BAIL ASSEMBLY          | SQ347-51 | 48    | O/S GEAR BUSHING         | N/A      |
| 18    | LINE ROLLER BUSHING    | N/A      | 48    | O/S GEAR BALL BEARING    | EH158-01 |
| 18    | LINE ROLLER BEARING    | GH202-01 | 49    | OSCILLATOR GEAR          | SQ053-51 |
| 19    | LINE ROLLER            | CH004-04 | 50    | OSCILLATOR SLIDER        | SQ025-01 |
| 20    | LINE ROLLER WASHER     | DH102-01 | 51    | MAIN SHAFT SCREW         | RQ100-01 |
| 21    | LINE ROLLER COLLAR     | CH102-01 | 52    | GEAR SHAFT BALL BEARING  | BL157-01 |
| 22    | ARM LEVER ASSEMBLY     | SQ307-02 | 53    | DRIVE GEAR ASSY          | RT312-01 |
| 23    | LINE SLIDER SCREW      | AQ108-07 | 54    | ADJUST WASHER            | GU105-13 |
| 24    | KICK LEVER             | SQ019-01 | 55    | GEAR SHAFT BALL BEARING  | BL157-01 |
| 25    | ARM LEVER COVER        | SQ087-01 | 56    | BODY COVER               | SQ023-55 |
| 26    | ARM LEVER COVER WASHER | SQ142-01 | 57    | BODY COVER SCREW WASHER  | RQ142-01 |
| 27    | ARM LEVER COVER SCREW  | GU077-15 | 58    | BODY COVER SCREW         | SQ057-01 |
| 28    | ROTOR ASSEMBLY         | SQ309-52 | 59    | BODY COVER SCREW         | RQ057-01 |
| 29    | CLUTCH ASSEMBLY        | SQ360-01 | 60    | HANDLE ASSEMBLY          | RT318-02 |
| 30    | CLUTCH WASHER          | RQ167-01 | 61    | CAM SPRING SCREW         | N/A      |
| 31    | CLUTCH SLEEVE          | SQ139-01 |       |                          |          |