


QUANTUM ENERGY

E860PTxm



Quantum Energy E860PTxm Part List

Key #	Description	Part No. E860PTxm	Key #	Description	Part No. E860PTxm
1	Palm Side Cover Assembly	SX323-01	38	Pinion Yoke Spring	CX040-01
2	Centrifugal Dial Washer	QV111-01	39	Pinion Gear Assembly	VW311-01
3	Centrifugal Dial Assembly	CX326-01	40	Release Slider Spring	CX104-01
4	Centrifugal Dial Spring	CX108-01	41	Thumb Bar Screw	ZW053-01
5	Spool Cover	CX051-01	42	Release Slider	CX039-01
6	Spool Cover Screw	QV125-01	43	Kick Lever	CX077-01
7	Spool Tension Shim	QW032-04	44	Thumb Bar	CX009-01
8	Spool Shaft Ball Bearing - Palm	QV017-01	45	Crank Shaft Ball Bearing -L	SW017-01
9	Clip Ring	HV080-01	46	E-Clip	QW120-01
10	Brake Ring Assembly	HV342-02	47	Crank Shaft Retainer	CX002-01
11	Brake Ring Retainer Spring	QV070-01	48	Crank Shaft Retainer Screw	JX107-01
12	Brake Ring Retainer Screw	CX076-01	49	Crank Shaft	CX008-01
13	Spool Assembly	AX321-02	50	O/S Drive Gear	ZW112-01
14	Clip Ring	HV080-01	51	Trip Ratchet	QW083-01
15	Spool Shaft Ball Bearing - Gear	JX106-01	52	Trip Ratchet Washer	QW111-03
16	Stabilizer Bar	CX061-01	53	Drive Gear	HV012-01
17	Gear Side Cover Screw	BV123-01	54	Drag Disc	SX059-02
18	Frame	CX001-06	55	Drag Key Washer	SX048-01
19	E-Clip	NX090-01	56	Link	SX036-01
20	Worm Shaft Washer	QW035-03	57	One Way Clutch Sleeve	SX052-01
21	Worm Shaft Bearing Retainer	CX067-01	58	Gear Side Cover Assembly	SX324-05
22	Worm Shaft	HV072-02	59	Spool Tension Knob O-Ring	QW101-01
23	Worm Shaft Guide	HV016-01	60	Spool Tension Knob Ball Bearing	SW117-01
24	Stabilizer Bar	CX061-01	61	Spool Tension Washer	QW032-04
25	Side Cover Locking Lever	CX119-01	62	Spool Tension Collar	QW081-01
26	Side Cover Locking Lever Spring	ZW096-01	63	Spool Cushion Washer	QW082-01
27	Front Support	SX099-01	64	Spool Tension Knob Assembly	CX333-03
28	Hood	CX027-06	65	Drag Click Spring Assembly	ZW4114
29	Worm Shaft Bushing - Gear	HV068-01	66	Spring "D" Washer	QW046-02
30	O/S Pinion Gear	HV085-01	67	Star Drag Washer	ZW032-02
31	E-Clip	NX090-01	68	Star Drag Assembly	CX355-03
32	Line Guide Carrier	CX047-01	69	Handle Washer	QW054-02
33	Line Guide Pawl	CX006-01	70	Handle Assembly	SX318-01
34	Line Guide Carrier Washer	BV035-01	71	Handle Nut	RV003-01
35	Line Guide Carrier Screw	ZW007-02	72	Handle Nut Cap	JX034-05
36	Kick Lever Spring	QV097-01	73	Handle Nut Cap Screw	QW123-01
37	Pinion Yoke	CX025-01	74	Worm Shaft Ball Bearing	XX117-01