

ENERGY (1 Series) E7-1 / E5-1 / E3-1 / E2-1 PARTS LIST

KEY NO.	E7-1	E5-1	E3-1	E2-1	DESCRIPTION
1	FH332-04	FH332-01	FH332-02	FH332-03	DRAG KNOB ASSEMBLY
2	AQ038-01	-	-	-	DRAG RETAINER
3	TU080-01	-	-	-	DRAG WASHER D
4	GH033-01	-	-	-	DRAG WASHER B
5	TU081-01	-	-	-	DRAG WASHER A
6	ZQ321-04	ZQ321-01	ZQ321-02	ZQ321-03	SPOOL ASSEMBLY
7	TU030-01	-	-	-	CLICK GEAR WASHER
8	TU037-01	-	-	-	CLICK GEAR
9	GU006-02	-	-	-	ROTOR NUT
10	TU065-01	-	-	-	ROTOR D WASHER
11	GH034-01	-	-	-	E-CUP
12	ZQ009-04	ZQ009-01	ZQ009-02	ZQ009-03	ROTOR
13	OL031-01	-	-	-	BALL SPRING SHAFT
14	KO049-05	-	-	-	BALL SPRING
15	OL020-01	-	-	-	BALL SPRING HOLDER
16	ZQ087-04	ZQ087-01	ZQ087-02	ZQ087-03	ARM LEVER SPRING COVER
17	UO057-01	-	-	-	SCREW
18	ZQ347-04	ZQ347-01	ZQ347-02	ZQ347-03	BALL ASSEMBLY
19	AO108-02	-	-	-	LINE SLIDER SCREW
20	ZQ007-04	ZQ007-01	ZQ007-02	ZQ007-03	ARM LEVER
21	GU105-25	-	-	-	LINE ROLLER WASHER
22	TU004-01	TU004-01	N/A	N/A	LINE ROLLER WITH BALL BEARING
23	N/A	N/A	GH016-01	GH016-01	LINE ROLLER BUSHING
24	N/A	N/A	GH004-01	GH004-01	LINE ROLLER
25	GU105-12	-	-	-	ROTOR WASHER
26	FH040-01	-	-	-	BEARING PLATE
27	GH049-01	-	-	-	KICK LEVER SPRING
28	ZQ019-01	-	-	-	KICK LEVER
29	ZQ024-04	ZQ024-01	ZQ024-02	ZQ024-03	KICK LEVER COVER
30	BL157-01	-	-	-	PINION BALL BEARING
31	TU052-01	-	-	-	BEARING SLEEVE

KEY NO.	E7-1	E5-1	E3-1	E2-1	DESCRIPTION
32	FH011-01	-	-	-	PINION
33	FH015-01	FH015-01	FH015-01	FH015-02	MAIN SHAFT
34	FH301-08	H301-04	FH301-05	FH301-06	BODY ASSEMBLY
35	FH200-01	-	-	-	LEVEL WIND GEAR
36	GH202-01	TU202-01	TU202-01	TU202-01	WORM SHAFT BUSHING LEFT
37	FH201-01	-	-	-	WORM SHAFT
38	FH204-01	-	-	-	PAWL HOLDER
39	TU207-01	-	-	-	PAWL
40	UO208-03	-	-	-	PAWL COLLAR
41	GU105-31	-	-	-	PAWL/LEVEL WIND WASHER
42	GH205-01	-	-	-	PAWL HOLDER RETAINER
43	UO100-02	-	-	-	MAIN SHAFT SCREW
44	GH202-02	GH203-01	GH203-01	GH203-01	WORM SHAFT BUSHING RIGHT
45	TU206-01	-	-	-	WORM SHAFT RETAINER
46	GH074-01	-	-	-	CLUTCH BEARING
47	GH077-01	-	-	-	ANTI-REVERSE PAWL SCREW
48	TU061-01	-	-	-	ANTI-REVERSE PAWL SPRING
49	TU091-01	-	-	-	ANTI-REVERSE PAWL POST
50	TU063-01	-	-	-	ANTI-REVERSE PAWL
51	GH089-01	-	-	-	ANTI-REVERSE LEVER SPRING
52	GH090-01	GH090-01	GH090-02	GH090-02	ANTI-REVERSE LEVER
53	BO105-01	-	-	-	HANDLE CAP WASHER
54	GH073-01	GH073-01	GH073-01	GH073-02	HANDLE CAP/SCREW
55A	BL157-01	BL157-01	GH013-01	GH013-01	BEARING
55B	BL157-01	BL157-01	BL157-01	GH013-01	BEARING
56	FH012-01	-	-	-	DRIVE GEAR
57	GU105-13	-	-	-	ADJUST WASHER
58	FH023-08	FH023-04	FH023-05	FH023-06	SIDECOVER
59	KO057-01	-	-	-	SIDECOVER SCREWS
60	FH318-03	FH318-01	FH318-02	GH318-03	HANDLE ASSEMBLY
61	GH212-01	N/A	N/A	N/A	WORM SHAFT COLLAR