


QUANTUM BR1/3-50



KEY PART NO.	BR150 PART NO.	BR350 PART NO.	DESCRIPTION	PRICE	KEY PART NO.	BR150 PART NO.	BR350 PART NO.	DESCRIPTION	PRICE
1	BH321-31	BH321-32	SPOOL ASSY.	7.75	28	BH046-31	BH046-31	ARM LEVER COVER	2.60
2	BH081-31	BH081-31	SPOOL WASHER 'A'	.55	29	BH085-11	BH085-11	COVER SCREW	.60
3	BH033-31	BH033-31	SPOOL WASHER 'B'	.60	30	BH007-11	BH007-12	ARM LEVER	3.00
4	BH080-31	BH080-31	SPOOL WASHER 'D'	.90	31	BH044-11	BH044-11	ARM LEVER SCREW	.60
5	BH038-31	BH038-31	DRAG RETAINER	.95	32	BH024-31	BH024-31	BAIL HOLDER COVER	1.65
6	BH332-31	BH332-31	DRAG KNOB ASSY.	3.10	33	BH085-11	BH085-11	COVER SCREW	.60
7	BH001-31	BH001-32	BODY	6.25	34	BH347-32	BH347-32	BAIL ASSY.	5.95
8	BH027-11	BH027-12	BEARING	5.95	35	BH016-11	BH016-11	LINE ROLLER BUSHING	1.00
9	BH090-11	BH090-11	STOPPER CAM	1.50	36	BH004-11	BH004-11	LINE ROLLER	5.30
10	BH089-11	BH089-11	STOPPER CAM SPRING	.90	37	BH044-11	BH044-11	BAIL HOLDER SCREW	.60
11	BH059-11	BH059-11	STOPPER LEVER	1.05	38	BH108-11	BH108-11	BAIL SCREW	.60
12	BH135-11	BH135-11	STOPPER LEVER SCREW	.60	39	BH110-31	BH110-31	BEARING WASHER	.50
13	BH061-11	BH061-11	STOPPER SPRING	1.40	40	BH086-31	BH086-31	SILENT SPRING	1.55
14	BH063-11	BH063-11	STOPPER	1.45	41	BH060-31	BH060-31	RATCHET GEAR	1.70
15	BH077-11	BH077-11	STOPPER SCREW	.60	42	BH006-31	BH006-31	ROTOR NUT	1.15
16	BH011-31	BH011-31	PINION GEAR	3.15	43	BH094-11	BH094-11	ROTOR NUT LOCK SCR	.60
17	BH028-31	BH028-31	BALL BEARING	7.00	44	BH315-31	BH315-31	MAIN SHAFT ASSY	5.95
18	BH041-11	BH041-11	BEARING SCREW	.60	45	BH100-11	BH100-11	MAIN SHAFT SCREW	.60
19	BH053-31	BH053-31	O/S GEAR	1.55	46	BH012-31	BH012-31	DRIVER GEAR	5.20
20	BH025-31	BH025-31	O/S SLIDER	2.55	47	BH026-11	BH026-11	ADJUST WASHER	.85
21	BH009-31	BH009-32	ROTOR	5.50	48	BH027-11	BH027-12	BEARING	5.95
22	BH049-31	BH049-31	KICK LEVER SPRING	.90	49	BH023-31	BH023-32	BODY COVER	5.25
23	BH019-31	BH019-31	KICK LEVER	1.85	50	BH057-31	BH057-31	BODY COVER SCREW	.60
24	BH136-11	BH136-11	KICK LEVER SCREW	.60	51	BH318-31	BH318-31	HANDLE ASSY.	7.25
25	BH020-11	BH020-11	SPRING HOLDER	.90	52	BH105-11	BH105-11	HANDLE CAP WASHER	.45
26	BH022-31	BH022-31	ARM LEVER SPRING	.60	53	BH073-31	BH073-31	HANDLE SCREW CAP	3.05
27	BH031-31	BH031-31	SPRING SHAFT	.90					

Prices subject to change without notice. Prices do not include postage and handling.

PLEASE ORDER BY PART NUMBER

Rev. 6/94

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-836-5581



BRUNSWICK