

# QUANTUM

## Xtralite XPS00



Key No.	Part Number	Description	Key No.	Part Number	Description
1	DO332-02	DRAG KNOB ASSEMBLY	27	FO219-01	BEARING HOUSING
2	DO038-01	DRAG RETAINER	28	DO028-01	BALL BEARING
3	DO105-01	DRAG WASHER "B"	29	FO139-01	CLUTCH SLEEVE
4	DO081-01	DRAG WASHER "A"	30	FO360-01	CLUTCH ASSEMBLY
5	DO080-01	DRAG WASHER "D"	31	FO216-01	CLUTCH SPRING
6	FO321-01	SPOOL ASSEMBLY	32	FO175-01	CLUTCH COVER
7	DO105-01	SPOOL ADJUSTMENT WASHER	33	DO011-01	PINION GEAR
8	DO037-01	CLICK GEAR	34	DO015-01	MAIN SHAFT
9	DO006-01	ROTOR NUT	35	FO318-01	HANDLE ASSEMBLY
10	DO347-01	BAIL ASSEMBLY	36	DO089-01	ANTI REVERSE LEVER SPRING
11	DO004-02	LINE ROLLER	37	DO001-03	BODY
12	DO102-01	LINE ROLLER COLLAR	38	DO057-02	BODY COVER SCREW
13	DO007-02	ARM LEVER	39	DO142-02	SIDE COVER RING
14	DO108-01	LINE SLIDER SCREW	40	DO023-02	BODY COVER
15	DO051-01	ARM LEVER SCREW	41	DO157-01	GEAR SHAFT BALL BEARING
16	DO085-01	ARM LEVER COVER SCREW	42	DO026-01	GEAR ADJUST WASHER
17	DO087-01	ARM LEVER SPRING COVER	43	DO012-01	DRIVE GEAR
18	DO049-01	ARM LEVER SPRING	44	DO104-01	OSCILLATOR CAM
19	DO009-02	ROTOR	45	DO100-01	MAIN SHAFT SCREW
20	DO017-01	BAIL HOLDER	46	DO025-01	OSCILLATOR SLIDER
21	DO051-01	ARM LEVER SCREW	47	DO140-01	BODY REAR COVER
22	DO085-01	ARM LEVER COVER SCREW	48	DO062-01	BODY REAR COVER SCREW
23	DO082-01	KICK LEVER COVER	49	DO090-01	ANTI REVERSE STOPPER LEVER
24	DO019-01	KICK LEVER	50	DO105-01	HANDLE CAP WASHER
25	FO041-01	BEARING PLATE SCREW	51	DO073-01	HANDLE SCREW CAP
26	FO040-01	BEARING PLATE			