



| Quantum Aruba |                                |          |         |                                     |           |
|---------------|--------------------------------|----------|---------|-------------------------------------|-----------|
| Key No.       | Description                    | Part No. | Key No. | Description                         | Part No.  |
| 1             | Clamp Nut Assembly             | JF319-01 | 45      | Reel Foot                           | KF106-01  |
| 2             | Clamp Nut Washer               | KF121-01 | 46      | Reel Foot Gasket                    | JF155-01  |
| 3             | Pre Set Knob Assembly          | KF329-01 | 47      | Reel Foot Screw                     | JF057-01  |
| 4             | Pre Set Knob Spring            | JF096-01 | 48      | Rod Clamp Bolt                      | JF125-01  |
| 5             | Pre Set Gear Washer - B        | KF038-01 | 49      | Rod Clamp Bolt Holder Nut           | JF003-01  |
| 6             | Pre Set Gear - A               | JF029-01 | 50      | Rod Clamp                           | JF154-01  |
| 7             | Pre Set Gear Washer - A        | JF035-01 | 51      | Rod Clamp Nut                       | KF003-01  |
| 8             | Pre Set Knob Locking Screw     | KF050-01 | 52      | Anti Reverse Pawl                   | JF063-01  |
| 9             | Pre Set Knob Locking Plate     | KF010-01 | 53      | E-Clip                              | NX092-01  |
| 10            | Clamp Nut Retainer             | JF075-01 | 54      | Anti Reverse Spring Holder Screw    | BV123-01A |
| 11            | Bait Click Acuator Pin         | JF102-01 | 55      | Anti Reverse Spring Holder          | KF129-01  |
| 12            | Bait Click Acuator             | JF157-01 | 56      | Anti Reverse Spring                 | JF070-01  |
| 13            | Bait Click Cam                 | JF156-01 | 57      | Anti Reverse Spring Post            | JF103-01  |
| 14            | Bait Click Cam Screw           | CW107-02 | 58      | Spool Shaft Assembly                | JF315-20  |
| 15            | Bait Click Spring              | JF110-01 | 59      | Crank Shaft Nut                     | KF019-01  |
| 16            | Bait Click Pawl                | JF114-01 | 60      | Spacer - A                          | JF160-01  |
| 17            | Frame Assembly                 | JF301-20 | 61      | Low Speed Drive Gear                | AF012-01  |
| 18            | Pre Set Idle Gear Click Plate  | KF113-01 | 62      | Spacer - B                          | KF160-01  |
| 19            | Pre Set Idle Gear Click Pin    | JF108-01 | 63      | Gear Shifting Plate                 | JF036-01  |
| 20            | Pre Set Idle Gear Click Spring | KF070-01 | 64      | High Speed Drive Gear               | NF012-01  |
| 21            | Pre Set Idle Gear              | JF112-01 | 65      | Washer                              | JF032-01  |
| 22            | Pre Set Idle Gear Screw        | KF057-01 | 66      | Crank Shaft                         | JF008-01  |
| 23            | Pre Set Gear - B               | JF085-01 | 67      | Gear Shifting Plate Spring          | KF096-01  |
| 24            | Drag Stopper Plate Washer      | KF032-01 | 68      | Shifting Pin                        | KF093-01  |
| 25            | Drag Stopper Plate Assembly    | JF310-01 | 69      | Bushing                             | JF132-01  |
| 26            | E-Clip                         | KF020-01 | 70      | Gear Shifting Spring                | KF165-01  |
| 27            | Left Drag Plate Assembly       | KF348-01 | 71      | Quadrant Anchor Screw               | KF053-01  |
| 28            | Pressure Release Spring        | KF040-01 | 72      | Gear Side Cover Assembly            | JF324-20  |
| 29            | Screw                          | TW107-02 | 73      | Quadrant                            | JF152-01  |
| 30            | Bait Click Ratchet             | JF113-01 | 74      | Quadrant Spacer                     | KF094-01  |
| 31            | Ball Bearing                   | KF017-01 | 75      | Quadrant Anchor                     | KF088-01  |
| 32            | Spool Assembly                 | JF321-01 | 76      | Handle Collar                       | JF081-01  |
| 33            | Drag Washer                    | JF045-01 | 77      | Handle Assembly                     | KF318-01  |
| 34            | Bushing                        | JF067-01 | 78      | Button Screw                        | JF053-01  |
| 35            | Ball Bearing                   | CP058-01 | 79      | Handle Nut                          | KF125-01  |
| 36            | Right Drag Plate Assembly      | JF348-01 | 80      | Handle Nut Retainer                 | JF034-01  |
| 37            | Low Speed Pinion Gear          | JF011-01 | 81      | Shifting Button Spring              | JF071-01  |
| 38            | High Speed Pinion Gear         | KF011-01 | 82      | High Speed Shifting Button Assembly | KF362-01  |
| 39            | Bearing Pocket                 | KF067-01 | 83      | Button Cover                        | JF131-01  |
| 40            | Drag Spring Washer             | JF046-01 | 84      | Handle Nut Cap                      | JF145-01  |
| 41            | Drag Cam - B                   | JF153-01 | 85      | Handle Nut Cap Screw                | KF123-01  |
| 42            | Drag Cam - A                   | JF028-01 | 86      | Low Speed Shifting Button           | JF062-01  |
| 43            | Bait Click Lever Spring Pin    | KF108-01 | 87      | Bait Click Lever                    | JF109-01  |
| 44            | Bait Click Lever Screw         | JF107-01 | 88      | Gear Cover                          | JF143-01  |