

Parts List for



KEY #	ICON-10	PULSE-10	ICON-20	PULSE-20	ICON-30	PULSE-30	ICON-40	PULSE-40	DESCRIPTION
1	PQ332-01	PQ332-02	RQ332-01	RQ332-02	SQ332-01	SQ332-02	TQ332-01	TQ332-02	DRAG KNOB ASSEMBLY
2	RQ038-01	RQ038-01	RQ038-01	RQ038-01	RQ038-01	RQ038-01	RQ038-01	RQ038-01	DRAG RETAINER
3	RQ080-01	RQ080-01	RQ080-01	RQ080-01	RQ080-01	RQ080-01	RQ080-01	RQ080-01	DRAG WASHER "D"
4	RQ033-01	RQ033-01	RQ033-01	RQ033-01	RQ033-01	RQ033-01	RQ033-01	RQ033-01	DRAG WASHER "B"
5	N/A	N/A	N/A	N/A	RQ080-01	RQ080-01	RQ080-01	RQ080-01	DRAG WASHER "D"
6	RQ081-01	RQ081-01	RQ081-01	RQ081-01	RQ081-01	RQ081-01	RQ081-01	RQ081-01	DRAG WASHER "A"
7	PQ160-01	PQ160-01	RQ160-01	RQ160-01	SQ160-01	SQ160-01	TQ160-01	TQ160-01	SPOOL SLEEVE
8	PQ321-01	PQ321-02	RQ321-01	RQ321-02	SQ321-01	SQ321-02	TQ321-01	TQ321-02	SPOOL ASSEMBLY
9	RQ030-01	RQ030-01	RQ030-01	RQ030-01	RQ030-01	RQ030-01	RQ030-01	RQ030-01	SPOOL WASHER
10	RQ037-01	RQ037-01	RQ037-01	RQ037-01	RQ037-01	RQ037-01	RQ037-01	RQ037-01	CLICK GEAR
11	RQ214-01	RQ214-01	RQ214-01	RQ214-01	SQ214-01	SQ214-01	SQ214-01	SQ214-01	MAIN SHAFT BUSHING
12	SH008-01	SH008-01	SH006-01	SH006-01	TH006-01	TH006-01	TH006-01	TH006-01	ROTOR NUT
13	RQ094-01	RQ094-01	RQ094-01	RQ094-01	RQ094-01	RQ094-01	RQ094-01	RQ094-01	ROTOR NUT LOCK SCREW
14	GH034-01	GH034-01	GH034-01	GH034-01	GH034-01	GH034-01	GH034-01	GH034-01	E-CLIP
15	PQ015-01	PQ015-01	RQ015-01	RQ015-01	SQ015-01	SQ015-01	TQ015-01	TQ015-01	MAIN SHAFT
16	GH034-01	GH034-01	GH034-01	GH034-01	GH034-01	GH034-01	GH034-01	GH034-01	E-CLIP
17	PQ347-01	PQ347-01	RQ347-01	RQ347-01	SQ347-01	SQ347-01	TQ347-01	TQ347-01	BAIL ASSEMBLY
18	DH018-01	DH018-01	DH018-01	DH018-01	DH018-01	DH018-01	DH018-01	DH018-01	LINE ROLLER BUSHING
18	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	LINE ROLLER BEARING
19	PQ004-01	PQ004-01	DH004-01	DH004-01	DH004-01	DH004-01	DH004-01	DH004-01	LINE ROLLER
20	PQ102-51	PQ102-51	DH102-01	DH102-01	DH102-01	DH102-01	DH102-01	DH102-01	LINE ROLLER WASHER
21	PQ102-01	PQ102-01	CH102-01	CH102-01	CH102-01	CH102-01	CH102-01	CH102-01	LINE ROLLER COLLAR
22	PQ307-01	PQ307-02	RQ307-01	RQ307-02	SQ307-01	SQ307-02	SQ307-01	SQ307-02	ARM LEVER ASSEMBLY
23	AQ108-01	AQ108-01	AQ108-01	AQ108-01	AQ108-01	AQ108-01	AQ108-01	AQ108-01	LINE SLIDER SCREW
24	PQ019-01	PQ019-01	RQ019-01	RQ019-01	SQ019-01	SQ019-01	TQ019-01	TQ019-01	KICK LEVER
25	PQ087-01	PQ087-01	RQ087-01	RQ087-01	SQ087-01	SQ087-01	TQ087-01	TQ087-01	ARM LEVER COVER
26	SQ142-01	SQ142-01	SQ142-01	SQ142-01	SQ142-01	SQ142-01	GU077-02	GU077-02	ARM LEVER COVER WASHER
27	GU077-02	GU077-02	GU077-02	GU077-02	GU077-02	GU077-02	TQ309-01	TQ309-02	ARM LEVER COVER SCREW
28	PQ309-01	PQ309-02	RQ309-01	RQ309-02	SQ309-01	SQ309-02	SQ309-01	SQ309-02	ROTOR ASSEMBLY
29	RQ360-01	RQ360-01	RQ360-01	RQ360-01	SQ360-01	SQ360-01	RQ167-01	RQ167-01	CLUTCH ASSEMBLY
30	RQ167-01	RQ167-01	RQ167-01	RQ167-01	RQ167-01	RQ167-01	SQ139-01	SQ139-01	CLUTCH WASHER

KEY #	ICON-10	PULSE-10	ICON-20	PULSE-20	ICON-30	PULSE-30	ICON-40	PULSE-40	DESCRIPTION
31	RQ139-01	RQ139-01	RQ139-01	RQ139-01	SQ139-01	SQ139-01	SQ139-01	SQ139-01	CLUTCH SLEEVE
32	CH028-01	CH028-01	BH028-01	BH028-01	UK028-01	UK028-01	UK028-01	UK028-01	PINION BALL BEARING
33	PQ011-01	PQ011-01	RQ011-01	RQ011-01	SQ011-01	SQ011-01	SQ011-01	SQ011-01	PINION GEAR
34	PQ141-01	PQ141-01	RQ141-01	RQ141-01	SQ141-01	SQ141-01	SQ141-01	SQ141-01	PINION BUSHING
35	RQ041-01	RQ041-01	RQ041-01	RQ041-01	RQ041-01	RQ041-01	RQ041-01	RQ041-01	BEARING SCREW
36	PQ061-01	PQ061-01	RQ061-01	RQ061-01	RQ061-01	RQ061-01	RQ061-01	RQ061-01	ANTI REVERSE PAWL SPRING
37	PQ063-01	PQ063-01	RQ063-01	RQ063-01	SQ063-01	SQ063-01	SQ063-01	SQ063-01	ANTI-REVERSE PAWL
38	RQ077-01	RQ077-01	RQ077-01	RQ077-01	RQ077-01	RQ077-01	RQ077-01	RQ077-01	ANTI-REVERSE PAWL SCREW
39	PQ090-01	PQ090-01	RQ090-01	RQ090-01	RQ090-01	RQ090-01	RQ090-01	RQ090-01	ANTI REVERSE CAM
40	PQ089-01	PQ089-01	RQ089-01	RQ089-01	RQ089-01	RQ089-01	RQ089-01	RQ089-01	ANTI REVERSE CAM SPRING
41	RQ059-01	RQ059-01	RQ059-01	RQ059-01	RQ059-01	RQ059-01	RQ059-01	RQ059-01	ANTI REVERSE LEVER
42	RQ073-01	RQ073-01	RQ073-01	RQ073-01	RQ073-01	RQ073-01	RQ073-01	RQ073-01	HANDLE CAP SCREW
43	TH105-01	TH105-01	TH105-01	TH105-01	TH105-01	TH105-01	TH105-01	TH105-01	HANDLE SCREW WASHER
44	PQ301-01	PQ301-02	RQ301-01	RQ301-02	SQ301-01	SQ301-02	SQ301-03	SQ301-04	BODY ASSEMBLY
45	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	BODY REAR COVER
46	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	BODY REAR COVER WASHER
47	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	BODY REAR COVER SCREW
48	PQ158-01	N/A	RQ158-01	N/A	RQ158-01	N/A	RQ158-01	N/A	O/S GEAR BUSHING
48	N/A	EH158-01	N/A	EH158-01	N/A	EH158-01	N/A	EH158-01	O/S GEAR BALL BEARING
49	PQ053-01	PQ053-51	RQ053-01	RQ053-51	SQ053-01	SQ053-51	TQ053-01	TQ053-51	OSCILLATOR GEAR
50	PQ025-01	PQ025-01	RQ025-01	RQ025-01	SQ025-01	SQ025-01	SQ025-01	SQ025-01	OSCILLATOR SLIDER
51	RQ100-01	RQ100-01	RQ100-01	RQ100-01	RQ100-01	RQ100-01	RQ100-01	RQ100-01	MAIN SHAFT SCREW
52	CH027-01	CH027-01	CH028-01	CH028-01	BL157-01	BL157-01	BL157-01	BL157-01	GEAR SHAFT BALL BEARING
53	PQ012-01	PQ012-01	RQ012-01	RQ012-01	SQ012-01	SQ012-01	SQ012-01	SQ012-01	DRIVE GEAR
54	GU105-08	GU105-08	GU105-08	GU105-08	GU105-13	GU105-13	GU105-13	GU105-13	ADJUST WASHER
55	CH028-01	CH028-01	CH028-01	CH028-01	BL157-01	BL157-01	BL157-01	BL157-01	GEAR SHAFT BALL BEARING
56	PQ023-01	PQ023-02	RQ023-01	RQ023-02	SQ023-01	SQ023-02	SQ023-03	SQ023-04	BODY COVER
57	RQ142-01	RQ142-01	RQ142-01	RQ142-01	RQ142-01	RQ142-01	RQ142-01	RQ142-01	BODY COVER SCREW WASHER
58	RQ057-01	RQ057-01	RQ057-01	RQ057-01	RQ057-01	RQ057-01	RQ057-01	RQ057-01	BODY COVER SCREW
59	RQ057-01	RQ057-01	N/A	N/A	N/A	N/A	N/A	N/A	BODY COVER SCREW
60	PQ318-01	PQ318-02	RQ318-01	RQ318-02	SQ318-01	SQ318-02	SQ318-01	SQ318-02	HANDLE ASSEMBLY
61	RQ062-01	RQ062-01	N/A	N/A	N/A	N/A	N/A	N/A	CAM SPRING SCREW