



KEY # DESCRIPTION

- 1 DRAG KNOB ASSEMBLY
- 2 DRAG RETAINER
- 3 KEY WASHER
- 4 DRAG WASHER
- 5 SPOOL ASSEMBLY

- 6 SPOOL WASHER
- 7 CLICK GEAR
- 8 SCREW
- 9 ROTOR NUT
- 10 E-CLIP
- 11 WASHER
- 12 MAIN SHAFT
- 13 ROTOR ASSEMBLY
- 14 SPRING
- 15 KICK LEVER
- 16 BAIL SEAT
- 17 SCREW
- 18 BAIL ASSEMBLY
- 19 LINE ROLLER BALL BEARING
- 20 LINE ROLLER
- 21 LINE ROLLER WASHER
- 22 ARM LEVER ASSEMBLY
- 23 LINE SLIDER SCREW
- 24 SCREW
- 25 SPRING
- 26 BAIL ARM FLIP LEVER
- 27 SCREW
- 28 SCREW
- 29 ANTI-REVERSE PLATE
- 30 BAIL KICK LEVER

KEY # DESCRIPTION

- 31 SPRING
- 32 BAIL KICK LEVER SEAT
- 33 BALANCE WEIGHT
- 34 ARM LEVER COVER
- 35 BUSHING
- 36 SPRING
- 37 BALL BEARING
- 38 PINION GEAR
- 39 SCREW
- 40 HANDLE CAP SCREW
- 41 HANDLE SCREW WASHER
- 42 BODY
- 43 ANTI-REVERSE PAWL SCREW
- 44 ANTI-REVERSE PAWL
- 45 ANTI-REVERSE CAM
- 46 FLIP SPRING
- 47 SCREW
- 48 ANTI-REVERSE LEVER
- 49 BALL BEARING
- 50 DRIVE GEAR
- 51 ADJUST WASHER
- 52 BALL BEARING
- 53 BODY COVER
- 54 BODY COVER SCREW
- 55 BODY REAR COVER
- 56 BODY REAR COVER SCREW
- 57 O/S GEAR BUSHING
- 58 O/S GEAR
- 59 O/S SLIDER
- 60 MAIN SHAFT SCREW
- 61 HANDLE ASSEMBLY (INCLUDING TWO BALL BEARINGS)