



KEY # DESCRIPTION

1	DRAG KNOB ASSEMBLY
2	DRAG RETAINER
3	KEY WASHER
4	DRAG WASHER
5	SPOOL ASSEMBLY
6	SPOOL WASHER
7	CLICK GEAR
8	SCREW
9	ROTOR NUT
10	E-CLIP
11	WASHER
12	MAIN SHAFT
13	ROTOR ASSEMBLY
14	SPRING
15	KICK LEVER
16	BAIL SEAT
17	SCREW
18	BAIL ASSEMBLY
19	LINE ROLLER BALL BEARING
20	LINE ROLLER
21	LINE ROLLER WASHER
22	ARM LEVER ASSEMBLY
23	LINE SLIDER SCREW
24	SCREW
25	SPRING
26	BAIL ARM FLIP LEVER
27	SCREW
28	SCREW
29	ANTI-REVERSE PLATE
30	BAIL KICK LEVER

KEY # DESCRIPTION

31	SPRING
32	BAIL KICK LEVER SEAT
33	BALANCE WEIGHT
34	ARM LEVER COVER
35	BUSHING
36	SPRING
37	BALL BEARING
38	PINION GEAR
39	SCREW
40	HANDLE CAP SCREW
41	HANDLE SCREW WASHER
42	BODY
43	ANTI-REVERSE PAWL SCREW
44	ANTI-REVERSE PAWL
45	ANTI-REVERSE CAM
46	FLIP SPRING
47	SCREW
48	ANTI-REVERSE LEVER
49	BALL BEARING
50	DRIVE GEAR
51	ADJUST WASHER
52	BALL BEARING
53	BODY COVER
54	BODY COVER SCREW
55	BODY REAR COVER
56	BODY REAR COVER SCREW
57	O/S GEAR BUSHING
58	O/S GEAR
59	O/S SLIDER
60	MAIN SHAFT SCREW
61	HANDLE ASSEMBLY (INCLUDING TWO BALL BEARINGS)