


QUANTUM

Xtralite XTS00



Key No.	Part Number	Description	Key No.	Part Number	Description
1	DO332-01	DRAG KNOB ASSEMBLY	26	DO061-01	ANTI REVERSE PAWL SPRING
2	DO038-01	DRAG RETAINER	27	DO060-01	RATCHET GEAR
3	DO105-01	DRAG WASHER "B"	28	DO028-01	BALL BEARING
4	DO081-01	DRAG WASHER "A"	29	DO011-01	PINION GEAR
5	DO080-01	DRAG WASHER "D"	30	DO015-01	MAIN SHAFT
6	DO321-01	SPOOL ASSEMBLY	31	DO035-01	E-CLIP
7	DO105-01	SPOOL ADJUSTMENT WASHER	32	DO091-01	ANTI REVERSE PAWL POST
8	DO037-01	CLICK GEAR	33	DO063-01	ANTI-REVERSE PAWL "A"
9	DO006-01	ROTOR NUT	34	DO041-01	BEARING SCREW
10	DO347-01	BAIL ASSEMBLY	35	DO089-01	ANTI REVERSE LEVER SPRING
11	DO004-01	LINE ROLLER	36	DO001-01	BODY
12	DO102-01	LINE ROLLER COLLAR	37	DO142-01	SIDE COVER RING
13	DO007-01	ARM LEVER	38	DO057-02	BODY COVER SCREW
14	DO108-01	LINE SLIDER SCREW	39	DO023-01	BODY COVER
15	DO051-01	ARM LEVER SCREW	40	DO157-01	GEAR SHAFT BALL BEARING
16	DO085-01	ARM LEVER COVER SCREW	41	DO012-01	DRIVE GEAR
17	DO087-01	ARM LEVER SPRING COVER	42	DO104-01	OSCILLATOR CAM
18	DO049-01	ARM LEVER SPRING	43	DO100-01	MAIN SHAFT SCREW
19	DO009-01	ROTOR	44	DO025-01	OSCILLATOR SLIDER
20	DO017-01	BAIL HOLDER	45	DO140-01	BODY REAR COVER
21	DO051-01	ARM LEVER SCREW	46	DO062-01	BODY REAR COVER SCREW
22	DO085-01	ARM LEVER COVER SCREW	47	DO090-01	ANTI REVERSE STOPPER LEVER
23	DO082-01	KICK LEVER COVER	48	DO105-01	HANDLE CAP WASHER
24	DO019-01	KICK LEVER	49	DO073-01	HANDLE SCREW CAP
25	DO086-01	SILENT CAM	50	DO318-01	HANDLE ASSEMBLY