



RELIANCE 40 Part List

Key No.	Description	Part No. REL40XPT	Q'TY	Key No.	Description	Part No. REL40XPT	Q'TY
1	Drag Knob Assembly	CAK332-01	1	26	Line Roller	CAK004-01	1
2	Spool Kit Include	CAK421-01	1	27	Line Roller Washer	EAK102-52	1
	2A - Retaining Ring	EAK172-01	1	28	Bail Wire Assembly	CAK347-01	1
	2B - Drag Washer "D"	CAK080-01	2	29	Rotor Adjust Washer	CAK065-01	1
	2C - Drag Washer "A"	CAK081-01	2	30	Pinion Ball Bearing Holder Screw	CAK051-01	3
	2D - Drag Washer "B"	CAK033-01	3	31	Pinion Ball Bearing Holder Unit	CAK322-01	1
	2E - Bushing	CAK058-01	1	32	Pinion Ball Bearing Holder Seal	CAK263-01	1
	2F - Spool Assembly	CAK321-01	1	33	Pinion Ball Bearing	UK028-08	1
	2G - Clicker Holder	EAK204-01	1	34	Pinion Ball Bearing Retainer	CAK040-01	1
	2H - Clicker	EAK103-01	1	35	Clutch Unit	CAK463-01	1
	2I - Clicker Spring	EAK068-01	1	36	Ball Bearing	TW058-11	3
	2J - Clicker Spring Screw	EAK114-01	1	37	Washer	CAK110-01	1
	2K - Clicker Screw	EAK246-01	1	38	Pinion	CAK011-01	1
	2L - Line Clip Spring	EAK049-01	1	39	Trip Bumper Screw	EAK123-01	1
	2M - Line Clip	CAK128-01	1	40	Rotor Brake Screw	EAK135-01	1
2N - Line Clip Screw	EAK114-01	1	41	Trip Bumper	CAK119-01	1	
3	Retainer Ring	EAK038-01	1	42	Rotor Brake	CAK145-01	1
4	Spool Ball Bearing	CH027-08	1	43	Handle Screw Cap	CAK073-01	1
5	Seal	CAK251-01	1	44	Handle Screw Cap Seal	CAK266-01	1
6	Spool Adjust Washer	CAK030-01	1	45	Cosmetic Ring Screw	EAK107-01	6
7	Main Shaft Assembly	CAK315-01	1	46	Cosmetic Ring	CAK142-01	2
8	Rotor Nut Retainer Screw	EAK094-01	3	47	Body	CAK001-01	1
9	Rotor Nut Retainer	EAK118-01	1	48	Side Cover Seal	CAK254-01	1
10	Rotor Nut Retainer Seal	CAK265-01	1	49	Drive Gear	CAK012-01	1
11	Rotor Nut	CAK006-01	1	50	Drive Gear Ball Bearing Seal Plate	CAK255-01	2
12	Rotor Seal	EAK264-01	1	51	Drive Gear Ball Bearing Seal	CAK262-01	2
13	Arm Lever Screw	EAK225-01	2	52	Drive Gear Ball Bearing Screw	EAK220-01	6
14	Bail Holder	CAK017-01	1	53	Side Cover	CAK023-01	1
15	Rotor	CAK009-01	1	54	Side Cover Screw	EAK057-02	1
16	Kick Lever	CAK019-01	1	55	Side Cover Screw	EAK057-01	2
17	Cam	CAK031-01	1	56	O/S Gear Assembly	CAK353-01	1
18	Coil Spring	CAK022-01	1	57	O/S Gear Screw	CAK111-01	1
19	Rotor Cover	CAK087-01	1	58	O/S Slider	CAK025-01	1
20	Rotor Cover Screw	EAK077-01	1	59	Main Shaft Screw	CAK100-01	1
21	Line Roller Screw	EAK108-01	1	60	Guide Pin	CAK211-01	1
22	Arm Lever	CAK007-01	1	61	O/S Slider Plate	CAK084-01	1
23	Line Roller Collar	CAK102-01	1	62	O/S Slider Plate Screw	EAK085-01	1
24	Line Roller Washer	EAK102-51	1	63	Handle Assembly	CAK318-01	1
25	Bushing	EAK016-01	2				