



QUANTUM[®]

Quantum RELIANCE 85 Spinning Reel Part List

Key No.	Description	Part No.	Q'TY	Key No.	Description	Part No.	Q'TY
		REL85XPT				REL85XPT	
1	Drag Knob Assembly	GAK332-01	1	28	Bail Wire Assembly	GAK347-01	1
2	Spool Kit Include	GAK421-01	1	29	Silent Ring	GAK059-01	1
	2A - Retaining Ring	EAK172-01	1	30	Coil Spring	GAK069-01	1
	2B - Drag Washer "D"	EAK080-01	3	31	Silent Ring Sleeve Unit	GAK378-01	1
	2C - Drag Washer "A"	EAK081-01	3	32	Pinion Ball Bearing Holder Screw	EAK051-01	3
	2D - Drag Washer "B"	EAK033-01	5	33	Pinion Ball Bearing Holder	GAK122-01	1
	2E - Bushing	EAK058-01	1	34	Pinion Ball Bearing Holder Seal	EAK263-01	1
	2F - Spool Assembly	GAK321-01	1	35	Pinion Ball Bearing	GAK028-01	4
	2G - Clicker Holder	EAK204-01	1	36	Pinion Ball Bearing Retainer	GAK040-01	1
	2H - Clicker	EAK103-01	1	37	Clutch Unit	GAK463-01	1
	2I - Clicker Spring	EAK068-01	1	38	Pinion	GAK011-01	1
	2J - Clicker Spring Screw	EAK114-01	1	39	Rotor Brake Screw	GAK135-01	2
2K - Clicker Screw	EAK246-01	1	40	Rotor Brake	GAK145-01	1	
3	Retainer Ring	EAK038-01	1	41	E-Clip	QW120-01	1
4	Spool Ball Bearing	KT158-05	1	42	Anti-Reverse Actuator	GAK090-01	1
5	Seal	EAK251-01	1	43	Anti-Reverse Actuator Spring	GAK089-01	1
6	Spool Adjust Washer	EAK030-01	1	44	Anti-Reverse Actuator Spring Spacer	EAK091-01	1
7	Main Shaft Assembly	GAK315-01	1	45	Handle Screw Cap	GAK073-01	1
8	Rotor Nut Retainer Screw	EAK094-01	3	46	Handle Screw Cap Seal	EAK266-01	1
9	Rotor Nut Retainer	GAK118-01	1	47	Cosmetic Ring Screw	EAK107-01	6
10	Rotor Nut Retainer Seal	GAK265-01	1	48	Cosmetic Ring	GAK142-01	2
11	Rotor Nut	GAK006-01	1	49	Body	GAK001-01	1
12	Rotor Seal	GAK264-01	2	50	Side Cover Seal	GAK254-01	1
13	Arm Lever Screw	EAK225-01	2	51	Drive Gear	GAK012-01	1
14	Bail Holder	GAK017-01	1	52	Drive Gear Ball Bearing Seal Plate	GAK255-01	2
15	Rotor	GAK009-01	1	53	Drive Gear Ball Bearing Seal	GAK262-01	2
16	Kick Lever	GAK019-01	1	54	Drive Gear Ball Bearing Screw	EAK220-01	6
17	Cam	GAK031-01	1	55	Side Cover	GAK023-01	1
18	Coil Spring	GAK022-01	1	56	Side Cover Screw	EAK057-02	1
19	Rotor Cover	GAK087-01	1	57	Side Cover Screw	EAK057-01	3
20	Rotor Cover Screw	EAK077-01	1	58	O/S Gear Assembly	GAK353-01	1
21	Line Roller Screw	EAK108-01	1	59	O/S Gear Screw	EAK111-01	1
22	Arm Lever	GAK007-01	1	60	Slider	GAK025-01	1
23	Line Roller Collar	EAK102-01	1	61	Main Shaft Screw(L)	GAK100-01	1
24	Line Roller Washer	EAK102-51	1	62	Main Shaft Screw(S)	GAK100-02	1
25	Bushing	EAK016-01	2	63	Guide Pin	GAK211-01	1
26	Line Roller	EAK004-01	1	64	O/S Slider Plate	GAK084-01	1
27	Line Roller Washer	EAK102-52	1	65	O/S Slider Plate Screw	EAK085-01	2
				66	Handle Assembly	GAK318-01	1