



Quantum Smoke SM101HPT Parts List

| Key # | Description | Part No. | | Key # | Description | Part No. | |
|-------|--------------------------------------|-----------|-----|-------|------------------------------|-----------|-----|
| | | SM101HPT | QTY | | | SM101HPT | QTY |
| 1 | Palm Side Cover Kit include | VB4323-01 | 1 | 35 | Release Slider | VB039-01 | 1 |
| | 1A - Palm Side Cover Assembly | VB323-01 | 1 | 36 | Release Slider Link | VB036-01 | 1 |
| | 1B - Centrifugal Dial | VB026-01 | 1 | 37 | Release Slider Link Screw | EW125-01 | 1 |
| | 1C - Centrifugal Dial Friction Ring | SB105-01 | 1 | 38 | Release Slider Screw | CX076-03 | 1 |
| | 1D - Centrifugal Dial Click Spring | VB114-01 | 1 | 39 | Pinion Yoke | TB025-01 | 1 |
| | 1E - Centrifugal Dial Click Pawl | PW098-01 | 1 | 40 | Yoke Spring | GX040-01 | 2 |
| | 1F - Spool Cover | VB051-01 | 1 | 41 | Pinion Gear | GB011-02 | 1 |
| | 1G - Space Washer | PW032-01 | 2 | 42 | Crank Shaft Ball Bearing - L | SW017-06 | 1 |
| | 1H - Spool Tension Shim | QW032-04 | 1 | 43 | E-Clip | QW120-01 | 1 |
| | 1J - Spool Shaft Ball Bearing - Palm | QV017-04 | 1 | 44 | Crank Shaft Retainer | UB002-01 | 1 |
| | 1K - Clip Ring | HV080-01 | 1 | 45 | Crank Shaft Retainer Screw | JX107-02 | 2 |
| | 1L - Spool Cover Screw | ZW053-03 | 4 | 46 | Crank Shaft | YW008-08 | 1 |
| | 1M - Brake Ring Assembly | VB342-01 | 1 | 47 | O/S Drive Gear | UB112-01 | 1 |
| | 1N - Brake Ring Slider Spring | UB040-01 | 3 | 48 | Trip Ratchet | PW083-02 | 1 |
| | 1P - Brake Ring Slider Spring Retain | UB129-01 | 1 | 49 | Trip Ratchet Washer | YW111-01 | 1 |
| | 1Q - Screw | DW107-03 | 3 | 50 | Drive Gear | GB012-02 | 1 |
| | 1R - Tethered Spring | UB070-01 | 1 | 51 | Drag Key Washer | PW048-01 | 2 |
| 2 | Spool Assembly | UB321-01 | 1 | 52 | Drag Disc - A | PW059-01 | 2 |
| 3 | Locking Lever Retainer Screw | KW107-01 | 2 | 53 | Drag "D" Washer | YW045-01 | 1 |
| 4 | Locking Lever Retainer "A" | UB056-02 | 1 | 54 | Drag Disc - B | YW059-01 | 1 |
| 5 | Locking Lever Spring | UB114-01 | 1 | 55 | Drag Washer | PW045-02 | 1 |
| 6 | Locking Lever Retainer "B" | UB136-02 | 1 | 56 | One Way Clutch Sleeve | UX052-02 | 1 |
| 7 | Thumb Bar Screw | CW125-01 | 2 | 57 | Clip Ring | EB080-01 | 1 |
| 8 | Thumb Bar Assembly | VB309-01 | 1 | 58 | Tension Knob Ball Bearing | SW017-06 | 1 |
| 9 | Locking Lever | VB062-01 | 1 | 59 | Gear Side Cover Assembly | VB324-02 | 1 |
| 10 | Frame | VB001-01 | 1 | 60 | Gear Side Cover Screw "A" | BV123-05 | 2 |
| 11 | E-Clip | NX092-01 | 1 | 61 | Gear Side Cover Screw "B" | BV123-06 | 1 |
| 12 | Bearing Retainer | VB067-01 | 1 | 62 | Tension Knob Click Spring | PW114-01 | 1 |
| 13 | Worm Shaft Ball Bearing | XX117-04 | 1 | 63 | Click Ratchet Retainer | YW080-01 | 1 |
| 14 | Worm Shaft Guide | SB016-01 | 1 | 64 | Tension Knob Click Ratchet | PW113-01 | 1 |
| 15 | Worm Shaft | UB072-01 | 1 | 65 | Spool Tension Shim | QW032-04 | 1 |
| 16 | Line Guide Carrier Assembly | UB347-01 | 1 | 66 | Space Washer | PW032-01 | 2 |
| 17 | Line Guide Pawl | CX006-01 | 1 | 67 | Spool Tension Cushion Washer | EX082-02 | 1 |
| 18 | Carrier Washer | BV035-01 | 1 | 68 | Spool Tension Knob | UB033-01 | 1 |
| 19 | Line Guide Carrier Screw | ZW007-01 | 1 | 69 | Crank Shaft Bearing | TW058-09 | 1 |
| 20 | Front Support Screw | KW107-01 | 3 | 70 | Crank Shaft Washer | TW035-02 | 1 |
| 21 | Front Support | VB099-01 | 1 | 71 | Drag Click Spring Assembly | YX4114-01 | 1 |
| 22 | Worm Shaft Bushing - Gear Side | PW068-01 | 1 | 72 | Spring "D" Washer | JX046-01 | 2 |
| 23 | O/S Pinion Gear Washer | EX035-01 | 1 | 73 | Star Drag Washer | ZW032-01 | 1 |
| 24 | O/S Pinion Gear | UB085-01 | 1 | 74 | Star Drag | VB055-01 | 1 |
| 25 | Pin | UB093-01 | 1 | 75 | Handle Washer | NX054-01 | 1 |
| 26 | Side Cover Screw | ZW053-05 | 1 | 76 | Handle Assembly | UB318-02 | 1 |
| 27 | Tethered Shaft Stop Screw | UB123-01 | 1 | 76A | Handle Knob Ball Bearing | EH158-07 | 4 |
| 28 | Kick Lever Plate | VB010-01 | 1 | 76B | Handle Knob Assembly | XW313-02 | 2 |
| 29 | Kick Lever Plate Screw | KW107-02 | 3 | 76C | Handle Knob Screw | QW123-01 | 2 |
| 30 | Kick Lever Spring | TB097-01 | 1 | 76D | Handle Knob Cap | XW115-02 | 2 |
| 31 | Kick Lever | YW077-01 | 1 | 77 | Handle Nut | UB003-02 | 1 |
| 32 | Kick Lever Guide Plate | SB161-01 | 1 | 78 | Handle Nut Retainer Assembly | UB334-01 | 1 |
| 33 | Kick Lever Guide Plate Screw | JX107-02 | 1 | 79 | Handle Nut Cap Screw | DW050-02 | 1 |
| 34 | Release Slider Spring | TB104-01 | 1 | | | | |