



Quantum Smoke SM101SPT Parts List

Key #	Description	Part No.		Key #	Description	Part No.	
		SM101SPT	QTY			SM101SPT	QTY
1	Palm Side Cover Kit include	VB4323-01	1	35	Release Slider	VB4323-01	1
	1A - Palm Side Cover Assembly	VB323-01	1	36	Release Slider Link	VB323-01	1
	1B - Centrifugal Dial	VB026-01	1	37	Release Slider Link Screw	VB026-01	1
	1C - Centrifugal Dial Friction Ring	SB105-01	1	38	Release Slider Screw	SB105-01	1
	1D - Centrifugal Dial Click Spring	VB114-01	1	39	Pinion Yoke	VB114-01	1
	1E - Centrifugal Dial Click Pawl	PW098-01	1	40	Yoke Spring	PW098-01	2
	1F - Spool Cover	VB051-01	1	41	Pinion Gear	VB051-01	1
	1G - Space Washer	PW032-01	2	42	Crank Shaft Ball Bearing - L	PW032-01	1
	1H - Spool Tension Shim	QW032-04	1	43	E-Clip	QW032-04	1
	1J - Spool Shaft Ball Bearing - Palm	QV017-04	1	44	Crank Shaft Retainer	QV017-04	1
	1K - Clip Ring	HV080-01	1	45	Crank Shaft Retainer Screw	HV080-01	2
	1L - Spool Cover Screw	ZW053-03	4	46	Crank Shaft	ZW053-03	1
	1M - Brake Ring Assembly	VB342-01	1	47	O/S Drive Gear	VB342-01	1
	1N - Brake Ring Slider Spring	UB040-01	3	48	Trip Ratchet	UB040-01	1
	1P - Brake Ring Slider Spring Retain	UB129-01	1	49	Trip Ratchet Washer	UB129-01	1
	1Q - Screw	DW107-03	3	50	Drive Gear	DW107-03	1
	1R - Tethered Spring	UB070-01	1	51	Drag Key Washer	UB070-01	2
2	Spool Assembly	UB321-01	1	52	Drag Disc - A	UB321-01	2
3	Locking Lever Retainer Screw	KW107-01	2	53	Drag "D" Washer	KW107-01	1
4	Locking Lever Retainer "A"	UB056-02	1	54	Drag Disc - B	UB056-02	1
5	Locking Lever Spring	UB114-01	1	55	Drag Washer	UB114-01	1
6	Locking Lever Retainer "B"	UB136-02	1	56	One Way Clutch Sleeve	UB136-02	1
7	Thumb Bar Screw	CW125-01	2	57	Clip Ring	CW125-01	1
8	Thumb Bar Assembly	VB309-01	1	58	Tension Knob Ball Bearing	VB309-01	1
9	Locking Lever	VB062-01	1	59	Gear Side Cover Assembly	VB062-01	1
10	Frame	VB001-01	1	60	Gear Side Cover Screw "A"	VB001-01	2
11	E-Clip	NX092-01	1	61	Gear Side Cover Screw "B"	NX092-01	1
12	Bearing Retainer	VB067-01	1	62	Tension Knob Click Spring	VB067-01	1
13	Worm Shaft Ball Bearing	XX117-04	1	63	Click Ratchet Retainer	XX117-04	1
14	Worm Shaft Guide	SB016-01	1	64	Tension Knob Click Ratchet	SB016-01	1
15	Worm Shaft	UB072-01	1	65	Spool Tension Shim	UB072-01	1
16	Line Guide Carrier Assembly	UB347-01	1	66	Space Washer	UB347-01	2
17	Line Guide Pawl	CX006-01	1	67	Spool Tension Cushion Washer	CX006-01	1
18	Carrier Washer	BV035-01	1	68	Spool Tension Knob	BV035-01	1
19	Line Guide Carrier Screw	ZW007-01	1	69	Crank Shaft Bearing	ZW007-01	1
20	Front Support Screw	KW107-01	3	70	Crank Shaft Washer	KW107-01	1
21	Front Support	VB099-01	1	71	Drag Click Spring Assembly	VB099-01	1
22	Worm Shaft Bushing - Gear Side	PW068-01	1	72	Spring "D" Washer	PW068-01	2
23	O/S Pinion Gear Washer	EX035-01	1	73	Star Drag Washer	EX035-01	1
24	O/S Pinion Gear	UB085-01	1	74	Star Drag	UB085-01	1
25	Pin	UB093-01	1	75	Handle Washer	UB093-01	1
26	Side Cover Screw	ZW053-05	1	76	Handle Assembly	ZW053-05	1
27	Tethered Shaft Stop Screw	UB123-01	1	76A	Handle Knob Ball Bearing	UB123-01	4
28	Kick Lever Plate	VB010-01	1	76B	Handle Knob Assembly	VB010-01	2
29	Kick Lever Plate Screw	KW107-02	3	76C	Handle Knob Screw	KW107-02	2
30	Kick Lever Spring	TB097-01	1	76D	Handle Knob Cap	TB097-01	2
31	Kick Lever	YW077-01	1	77	Handle Nut	YW077-01	1
32	Kick Lever Guide Plate	SB161-01	1	78	Handle Nut Retainer Assembly	SB161-01	1
33	Kick Lever Guide Plate Screw	JX107-02	1	79	Handle Nut Cap Screw	JX107-02	1
34	Release Slider Spring	TB104-01	1			TB104-01	