


# GENIUS

## DIAGRAM



## PART LIST

No.	Part List	No.	Part List	No.	Part List
1.	Drag Knob	23.	Line Roller	45.	One Way Housing
2.	Drag Nut	24.	Ball Bearing 4 x 7 x 2.5	46.	One Way Cam
3.	Drag Click Claw	25.	Line Roller Bush	47.	Body
4.	Drag Coil Spring	26.	Arm Lever s/c	48.	Dust Cover
5.	Front Drag Under Cap	27.	Rotor	49.	Dust Cover w/s
6.	Drag Knob Cover	28.	Bail Spring Holder	50.	Main Shaft Bush
7.	Drag Knob Cover s/c	29.	Bail Spring	51.	Ball Bearing 7 x 11 x 2.5
8.	Spool Ring	30.	Bail Spring Cover	52.	Drive Gear
9.	Spool "D" w/s	31.	Bail Spring Cover s/c	53.	Drive Gear Adj. w/s
10.	Spool "B" w/s	32.	Kick Lever Spring	54.	Ball Bearing 7 x 13 x 4
11.	Spool "A" w/s	33.	Kick Lever	55.	Body Cover
12.	Spool Assy	34.	Kick Lever Cover	56.	Body Cover s/c
13.	Spool Adj. w/s	35.	Kick Lever Cover s/c	57.	Handle Assy
14.	Click Gear	36.	Side Balance	58.	O/S Gear
15.	Main Shaft	37.	Ball Bearing Cover s/c	59.	O/S Slider
16.	Rotor Nut Lock s/c	38.	Ball Bearing Cover	60.	Main Shaft s/c
17.	Rotor Nut	39.	Ball Bearing 7 x 13 x 4	61.	Body Rear Cap
18.	Bail Holder s/c	40.	Ball Bearing Holder	62.	Body Rear Cap s/c
19.	Bail Assy	41.	One Way Sleeve	63.	Stopper Lever s/p
20.	Bail s/c	42.	Pinion Gear	64.	Stopper Lever
21.	Arm Lever	43.	One Way Pin Roller	65.	Spool Bush
22.	Bail w/s	44.	One Way Pin Retainer	66.	Ball Bearing 5 x 9 x 3