


OPTIMA

DIAGRAM



PART LIST

| No. | Part List | No. | Part List | No. | Part List |
|-----|--------------------------|-----|---------------------------|-----|--------------------------|
| 1. | Push Button | 22. | Kick Lever Cover s/c | 43. | Ball Bearing 7 x 13 x 4 |
| 2. | Spool Lock Spring | 23. | Kick Lever Cover | 44. | Body Cover Assy |
| 3. | Spool Cap | 24. | Kick Lever | 45. | Body Cover s/c |
| 4. | Spool Assy | 25. | Kick Lever Spring | 46. | Handle Assy |
| 5. | Main Shaft Assy | 26. | Side Balance | 47. | O/S Gear |
| 6. | Rotor Nut Lock s/c | 27. | Ball Bearing Cover s/c | 48. | O/S Slider |
| 7. | Rotor Nut | 28. | Ball Bearing Cover | 49. | O/S Slider Stopper |
| 8. | Bail Holder s/c | 29. | Ball Bearing 7 x 13 x 4 | 50. | O/S Slider Stopper s/c |
| 9. | Bail Assy | 30. | Ball Bearing Holder | 51. | Stopper Lever s/p |
| 10. | Bail s/c | 31. | One Way Sleeve | 52. | Stopper Lever |
| 11. | Arm Lever | 32. | Pinion Gear | 53. | Back Click Claw |
| 12. | Bail w/s | 33. | One Way Pin Roller | 54. | Washer "E" (RD) |
| 13. | Line Roller | 34. | One Way Pin Retainer | 55. | Main Shaft Holder |
| 14. | Ball Bearing 4 x 7 x 2.5 | 35. | One Way Housing | 56. | Washer "B" Abbestos (RD) |
| 15. | Line Roller Bush | 36. | One Way Cam | 57. | Drag "A" w/s (RD) |
| 16. | Arm Lever s/c | 37. | Body | 58. | Drag "B" w/s (RD) |
| 17. | Rotor | 38. | Dust Cover | 59. | Drag "D" w/s (RD) |
| 18. | Bail Spring Holder | 39. | Dust Cover w/s | 60. | Rear Drag Slider |
| 19. | Bail Spring | 40. | Ball Bearing 7 x 11 x 2.5 | 61. | Rear Drag Coil s/p |
| 20. | Bail Spring Cover | 41. | Drive Gear | 62. | Rear Drag Knob Retainer |
| 21. | Bail Spring Cover s/c | 42. | Drive Gear Adj. w/s | 63. | Rear Drag Knob |