


OPTIMA

DIAGRAM



PART LIST

No.	Part List	No.	Part List	No.	Part List
1.	Push Button	22.	Kick Lever Cover s/c	43.	Ball Bearing 7 x 13 x 4
2.	Spool Lock Spring	23.	Kick Lever Cover	44.	Body Cover Assy
3.	Spool Cap	24.	Kick Lever	45.	Body Cover s/c
4.	Spool Assy	25.	Kick Lever Spring	46.	Handle Assy
5.	Main Shaft Assy	26.	Side Balance	47.	O/S Gear
6.	Rotor Nut Lock s/c	27.	Ball Bearing Cover s/c	48.	O/S Slider
7.	Rotor Nut	28.	Ball Bearing Cover	49.	O/S Slider Stopper
8.	Bail Holder s/c	29.	Ball Bearing 7 x 13 x 4	50.	O/S Slider Stopper s/c
9.	Bail Assy	30.	Ball Bearing Holder	51.	Stopper Lever s/p
10.	Bail s/c	31.	One Way Sleeve	52.	Stopper Lever
11.	Arm Lever	32.	Pinion Gear	53.	Back Click Claw
12.	Bail w/s	33.	One Way Pin Roller	54.	Washer "E" (RD)
13.	Line Roller	34.	One Way Pin Retainer	55.	Main Shaft Holder
14.	Ball Bearing 4 x 7 x 2.5	35.	One Way Housing	56.	Washer "B" Abbestos (RD)
15.	Line Roller Bush	36.	One Way Cam	57.	Drag "A" w/s (RD)
16.	Arm Lever s/c	37.	Body	58.	Drag "B" w/s (RD)
17.	Rotor	38.	Dust Cover	59.	Drag "D" w/s (RD)
18.	Bail Spring Holder	39.	Dust Cover w/s	60.	Rear Drag Slider
19.	Bail Spring	40.	Ball Bearing 7 x 11 x 2.5	61.	Rear Drag Coil s/p
20.	Bail Spring Cover	41.	Drive Gear	62.	Rear Drag Knob Retainer
21.	Bail Spring Cover s/c	42.	Drive Gear Adj. w/s	63.	Rear Drag Knob