


DIAGRAM



PART LIST

No.	Part List	No.	Part List	No.	Part List
1.	Drag Knob	23.	Bail s/c	45.	One Way Pin Roller Retainer
2.	Drag Nut	24.	Arm Lever	46.	One Way Housing
3.	Drag Click Spring	25.	Line Roller	47.	One Way Cam
4.	Drag Click Pin	26.	Ball Bearing 5 x 8 x 2.5	48.	Body
5.	Drag Coil Spring	27.	Arm Lever s/c	49.	Body Side Cap
6.	Drag Under Cap s/c	28.	Rotor	50.	Body Side Cap s/c
7.	Drag Under Cap	29.	Side Balance	51.	O/S Gear
8.	Ball Bearing 5 x 9 x 3	30.	Bail s/p	52.	O/S Slider
9.	Spool Bush	31.	Bail s/p Holder	53.	Main Shaft s/c
10.	Spool Ring	32.	Bail s/p Cover	54.	Stopper Lever s/p
11.	Spool "D" w/s	33.	Bail s/p Cover s/c	55.	Stopper Lever
12.	Spool "B" w/s	34.	Kick Lever s/p	56.	Ball Bearing 8 x 14 x 4
13.	Spool "A" w/s	35.	Kick Lever	57.	Drive Gear
14.	Spool Assy	36.	Kick Lever Cover	58.	Drive Gear Adj. w/s
15.	Spool Adj. w/s	37.	Kick Lever Cover s/c	59.	Ball Bearing 8 x 14 x 4
16.	Click Gear	38.	Ball Bearing Cover s/c	60.	Body Cover
17.	Main Shaft	39.	One Way B/B Cover	61.	Body Cover s/c
18.	Rotor Nut Lock s/c	40.	Ball Bearing 8 x 14 x 4	62.	Handle Assy
19.	Rotor Nut	41.	Ball Bearing Holder	63.	Body Rear Cap
20.	Center Balance	42.	One Way Sleeve	64.	Body Rear Cap s/c
21.	Bail Holder s/c	43.	Pinion Gear	65.	Dust Cover w/s
22.	Bail Assy	44.	One Way Pin Roller	66.	Dust Cover