


# Vi Gold Series



## PART LIST

No.	Part List	No.	Part List
1.	Drag Knob Assy	29.	Kick Lever s/c
2.	Spool Ring	30.	Ball Bearing Cover s/c
3.	Spool "D" w/s	31.	Kick Lever Guide
4.	Spool "B" w/s	32.	Ball Bearing Cover Plate
5.	Spool "A" w/s	33.	Ball Bearing
6.	Spool Assy	34.	Pinion Collar
7.	Spool Adj. w/s	35.	Ratchet Gear
8.	Click Gear	36.	Pinion Gear
9.	Main Shaft	37.	Body
10.	Bail Assy	38.	Stopper Lever
11.	Bail Holder s/c	39.	Stopper Lever s/p
12.	Line Roller	40.	Stopper
13.	Bail Collar	41.	Stopper s/p
14.	Arm Lever	42.	Stopper s/c
15.	Arm Lever s/c	43.	O/S Gear
16.	Bail s/c	44.	O/S Gear s/c
17.	Rotor Nut	45.	O/S Slider
18.	Rotor Nut Lock Spring w/s	46.	Main Shaft s/c
19.	Rotor	47.	Ball Bearing
20.	Bail s/p	48.	Silent s/p
21.	Rotor Cover	49.	Brass Drive Gear
22.	Rotor Cover s/c	50.	Drive Gear Adj. w/s
23.	Center Balance s/c	51.	Ball Bearing
24.	Center Balance	52.	Body Cover
25.	Bail Holder Balance	53.	Body Cover s/c
26.	Side Balance	54.	Handle Assy
27.	Kick Lever s/p	55.	Handle s/c Cap
28.	Kick Lever		