



PART LIST

No.	Part List	No.	Part List
1.	Drag Knob Assy	31.	Kick Lever Guide
2.	Spool Ring	32.	Ball Bearing Cover Plate
3.	Spool "D" w/s	33.	Ball Bearing
4.	Spool "B" w/s	34.	Pinion Collar
5.	Spool "A" w/s	35.	Ratchet Gear
6.	Spool Assy	36.	Pinion Gear
7.	Spool Adj. w/s	37.	Body
8.	Click Gear	38.	Stopper Lever
9.	Main Shaft	39.	Stopper Lever s/p
10.	Bail Assy	40.	Stopper
11.	Bail Holder s/c	41.	Stopper s/p
12.	Line Roller	42.	Stopper s/c
13.	Bail Collar	43.	O/S Gear
14.	Arm Lever	44.	O/S Gear s/c
15.	Arm Lever s/c	45.	O/S Slider
16.	Bail s/c	46.	Main Shaft s/c
17.	Rotor Nut	47.	Ball Bearing
18.	Rotor Nut Lock Spring w/s	48.	Silent s/p
19.	Rotor	49.	Brass Drive Gear
20.	Bail s/p	50.	Drive Gear Adj. w/s
21.	Rotor Cover	51.	Ball Bearing
22.	Rotor Cover s/c	52.	Body Cover
23.	Center Balance s/c	53.	Body Cover s/c
24.	Center Balance	54.	Handle Assy
25.	Bail Holder Balance	55.	Ball Bearing
26.	Side Balance	56.	Handle Knob Stand
27.	Kick Lever s/p	57.	Handle s/c
28.	Kick Lever	58.	Wood Handle Knob
29.	Kick Lever s/c	59.	Handle s/c Cap
30.	Ball Bearing Cover s/c		