


DIAGRAM



PART LIST

No.	Part List	No.	Part List	No.	Part List
1.	Drag Knob	22.	Arm Lever	43.	One Way Pin Roller Retainer
2.	Drag Nut	23.	Line Roller	44.	One Way Housing
3.	Drag Click Spring	24.	Ball Bearing 5 x 8 x 2.5	45.	One Way Cam
4.	Drag Click Pin	25.	Arm Lever s/c	46.	Body
5.	Drag Coil Spring	26.	Rotor	47.	O/S Gear
6.	Drag Under Cap	27.	Kick Lever s/p	48.	O/S Slider
7.	Drag Under Cap s/c	28.	Kick Lever	49.	Main Shaft s/c
8.	Spool Ring	29.	Kick Lever Cover	50.	Stopper Lever s/p
9.	Spool "D" w/s	30.	Kick Lever Cover s/c	51.	Stopper Lever
10.	Spool "B" w/s	31.	Side Balance	52.	Ball Bearing 8 x 14 x 4
11.	Spool "A" w/s	32.	Bail s/p	53.	Drive Gear
12.	Spool Assy	33.	Bail s/p Holder	54.	Drive Gear Adj. w/s
13.	Spool Adj. w/s	34.	Bail s/p Cover	55.	Ball Bearing 8 x 14 x 4
14.	Click Gear	35.	Bail s/p Cover s/c	56.	Body Cover
15.	Main Shaft	36.	One Way B/B Cover	57.	Body Cover s/c
16.	Rotor Nut Lock s/c	37.	Ball Bearing Cover s/c	58.	Handle Assy
17.	Rotor Nut	38.	Ball Bearing 8 x 14 x 4	59.	Body Under Cap
18.	Center Balance	39.	Ball Bearing Holder	60.	Body Under Cap s/c
19.	Bail Holder s/c	40.	One Way Sleeve	61.	Dust Cover w/s
20.	Bail Assy	41.	Pinion Gear	62.	Dust Cover
21.	Bail s/c	42.	One Way Pin Roller		