



NO	PARTS NAMES	NO	PARTS NAMES
1	Left side plate	42	Decorative piece B
2	Brake adjusting knob	43	Right side plate screw
3	Click leaf spring A	44	P/n A
4	Rotation seat	45	Worm shaft gear A
5	Magnet holder	46	Worm shaft
6	Rotation seat screw	47	Line guide assembly
7	Quick switch spring	48	Line guide pawl
8	Quick switch-plate	49	Pawl cap
9	Fixed pivot	50	Front plate
10	Screw A	51	Worm shield
11	Screw B	52	Stabilizer bar
12	Quick switch	53	Ball bearing C (*1)
13	Magnet holder spring	54	Drive shaft retainer
14	Magnet suction disc	55	Drive shaft retainer screw A
15	Magnet	56	Drive shaft retainer screw B
16	Left set plate	57	E-retainer B
17	Spacer A	58	Anti-reverse ratchet
18	Spacer B	59	Worm shaft gear B
19	Ball bearing A (*2)	60	Drive shaft
20	Bearing retainer A	61	Drive shaft washer
21	Spool assembly	62	Drive gear
22	Clutch lever	63	Carbon drag washer A
23	Frame assembly	64	Key washer A
24	Bushing A	65	Carbon drag washer B
25	Bushing B	66	Ear-washer
26	Clutch cam A	67	Key washer B
27	Clutch cam B	68	One way clutch bushing
28	Clutch cam spring	69	One way clutch
29	Yoke	70	Ball bearing D (*1)
30	Clutch trip plate	71	Washer A
31	Clutch trip plate spring	72	Click leaf spring holder
32	Clutch trip plate washer	73	Click leaf spring B
33	E-retainer A	74	Drag spring washer
34	Yoke spring	75	Washer B
35	Pinion gear	76	Star drag assembly
36	Bearing retainer B	77	Friction washer
37	Ball bearing B (*4)	78	Handle assembly (*288)
38	Right side plate assembly	79	Handle nut
39	O-ring	80	Handle nut retainer
40	Cast control cap	81	Handle nut retainer screw
41	Decorative piece A		