
WARHEAD SW

5+1	(59)	(81)	(95)	(39)	(28)				(50)
7+1	(59)	(81)	(95)	(39)	(28)	(05)	(05)		(50)
9+1	(59)	(81)	(95)	(39)	(28)	4*(A)			(50)
10+1	(59)	(81)	(95)	(39)	(28)	4*(A)	(05)		(50)
11+1	(59)	(81)	(95)	(39)	(28)	4*(A)	(05)	(05)	(50)



PART#	DESCRIPTION
1	FRAME
2	LINE GUIDE
3	LEVEL WIND TUBE
4	WORD SHAFT
5	BALL BEARING(4*7*2.5)
6	WORD SHAFT GEAR
7	WORD SHAFT PIN
8	WORD SHAFT PIN HOLDER
9	WASHER
10	RETAINER
11	LINE GUIDE SHAFT
12	PAWL
13	WASHER
14	LINE GUIDE NUT
15	FRONT COVER
16	SCREW
17	KICK LEVER
18	KICK LEVER SPRING
19	CLUTCH SPRING
20	LIFT CURVE
21	LIFT CURVE PLATE
22	SCREW
23	SCREW
24	THUMB BAR
25	THUMB BAR SCREW
26	RETAINER
27	WASHER
28	BALL BEARING(5*9*3)
29	MAIN GEAR SHAFT PLATE
30	SCREW
31	WASHER

PART#	DESCRIPTION
32	LEVEL WIND GEAR
33	MAIN GEAR SHAFT
34	RATCHET
35	DRAG WASHER
36	MAIN GEAR
37	DRAG WASHER
38A	PRESSURE WASHER
38B	WASHER
38C	WASHER
39	BALL BEARING(8*14*3.5)
40	IAR SLEEVE
41	YOKE
42	SPRING
43	PINION
44	LOCK PIN
45	RETAINER
46	SPRING
50	ONE WAY CLUTCH
51	GEAR SIDE PLATE
52	O RING
53	BRAKE KNOB
54	RUBBER WASHER
55	FRICTION WASHER
56	TICK SEAT CONNECTING PLATE
57	RING
58	TICK SEAT
59	BALL BEARING(5*8*2.5)
60	RING
61	TICK PIN
62	SPRING
63	SCREW

PART#	DESCRIPTION
64	SCREW
65	DECORATION
66	WASHER
67	TICK SHRAPEL SEAT
68	SPRING WASHER
69	TICK SHRAPEL
70	WASHER
71	HANDLE
72	STAR WHEEL
75	EVA RNOB
76	RNOB COVER
77	HANDLE NUT
78	HANDLE NUT COVER
79	SCREW
80	SPOOL
81	BALL BEARING(5*11*4)
82	SPOOL SHAFT PIN
84	PALM SIDE PLATE
85	MAG DIAL
86	CLICK SPRING
87	SLIDE CAM
88	BEARING HOUSING
89	SPRING
90	MAGNET PLATE
91	MAGNET HOLDER
92	MAGNET
93	SCREW
94	FRICTION WASHER
95	BALL BEARING(3*10*4)
96	RING
A	BALL BEARING(5*8*2.5)*4

ReelSchematic