



- 1. Spool Plate
- 2. Spool Click Ring
- 3. Click Spring Seat
- 4. Flat Hole Washer
- 5. Line Block Ring Ball Bearing
- 6. Line Block Ring
- 7. O Ring 4.2x1
- 8. Line Block Ring Gasket A27
- 9. Line Block Ring Gasket B28
- 10. E5.0 Retainer
- 11. Rotor Nut
- 12. Roller Screw
- 13. Rotor Fixed Gasket
- 14. Rotor
- 15. E3.0 Retainer
- 16. Line Roller Bushing
- 17. Line Roller
- 18. Line Roller Washer
- 19. Bail Arm

- 20. Line Roller Screw
- 21. Ball Holder/Arm Locating Pin
- 22. Ball Holder/Arm Cover Screw
- 23. Ball Arm Cover
- 24. Ball Spring
- 25. Ball Spring Guide
- 26. Ball Arm Lever
- 27. Ball Ass'y
- 28. One Way Fixed Screw
- 29. Pinion Gear Ball Bearing Plate
- 30. Dust Cover
- 31. Anti Reverse Slice
- 32. Pinion Gear Ball Bearing A
- 33. Main Shaft
- 34. Bearing Bushing
- 35. One Way Ball Bearing
- 36. Pinion Gear Ball Bearing B
- 37. Pinion Gear
- 38. Main Shaft Sleeve

- 39. Worm Shaft Ball Bearing A
- 40. Oscillation Slide Screw
- 41. Oscillation Slide
- 42. Cover Screw
- 43. Oscillation Slide Cover
- 44. Line Guide Pawl Bushing
- 45. Line Guide Pawl
- 46. Guide Bushing Spring
- 47. Oscillation Slide Guide Bushing
- 48. Worm Shaft
- 49. Worm Shaft Gear
- 50. Worm Shaft Ball Bearing B
- 51. Anti Reverse Lever Knob
- 52. Anti Reverse Level Knob Screw
- 53. Anti Reverse Lever
- 54. Anti Reverse Lever Spring
- 55. One Way Ball Bearing Spring
- 56. Body
- 57. Handle Cap Washer

- 58. Handle Cap
- 59. Oscillation Gear Pin
- 60. Oscillation Gear
- 61. Body Ball Bearing
- 62. Drive Gear
- 63. Body Cover Ball Bearing
- 64. Body Cover
- 65. 2.6x10 Body cover screw
- 66. 3.0x10 Body cover screw
- 67. Body Logo plate
- 68. Body Cover Logo Plate
- 69. Body Rear Cover Screw
- 70. Spool
- 71. 101-335 Drag Washer
- 72. Drag ASSY
- 73. Spool Stop Ring
- 74. Drag Knob Ass'y
- 75. Handle Ass'y