



- | | | |
|------------------------------|----------------------------------|------------------------------------|
| 1 DRAG KNOB | 18 BAIL ASSEMBLY | 37 BODY BALL BEARING |
| 2 SPOOL ASSEMBLY | 19 BAIL HOLDER SHAFT SCREW | 38 DRIVER GEAR |
| 3 SPOOL CLICKER | 20 BAIL | 39 BODY COVER BALL BEARING |
| 4 MAIN SHAFT | 21 LINE ROLLER SHAFT | 40 BODY COVER |
| 5 PINION GEAR SCREW CAP | 22 BAIL HOLDER | 41 BODY COVER SCREW |
| 6 ROTOR WASHER | 23 SILENCE RING BUSHING WASHER | 42 HANDLE ASSEMBLY |
| 7 ROTOR | 24 SILENCE RING | 43 OSCILLATING GEAR |
| 8 KICK LEVER | 25 SILENCE RING BUSHING | 44 OSCILLATING SLIDE |
| 9 BAIL ARM SPRING | 26 BALL BEARING FIXED SCREW | 45 OSCILLATING SLIDE SCREW |
| 10 BAIL ARM SIDE COVER | 27 PINION BALL BEARING | 46 BODY |
| 11 BAIL ARM SIDE COVER SCREW | 28 ANTI-REVERSE PAWL FIXED SCREW | 47 BODY BACK DECORATED COVER |
| 12 BAIL ARM FIXED SCREW | 29 ANTI-REVERSE PAWL | 48 BODY BACK DECORATED COVER SCREW |
| 13 LINE ROLLER SCREW | 30 PINION | 49 DRAG WASHER RETAINER |
| 14 BAIL ARM | 31 ANTI-REVERSE LEVER | 50 KEY WASHER |
| 15 LINE ROLLER WASHER | 32 ANTI-REVERSE SWITCH | 51 WASHER |
| 16 LINE ROLLER BALL BEARING | 33 ANTI-REVERSE SWITCH SCREW | 52 EAR WASHER |
| 17 LINE ROLLER | 34 PINION GEAR SCREW CAP | 53 SPOOL |
| | 35 HANDLE SCREW CAP | 54 LINE HOOK |
| | 36 HANDLE SCREW CAP WASHER | 55 SPOOL CLICKER |